


Honeywell

CT40/CT40 XP Series

Mobile Computers
powered by Android™



User Guide

Disclaimer

Honeywell International Inc. (“HII”) reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult HII to determine whether any such changes have been made. HII makes no representation or warranties regarding the information provided in this publication.

HII shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material. HII disclaims all responsibility for the selection and use of software and/or hardware to achieve intended results.

This document contains proprietary information that is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated into another language without the prior written consent of HII.

Copyright © 2024 Honeywell Group of Companies. All rights reserved.

Website address: sps.honeywell.com.

Trademarks

Google, Android, Google Play, Google Pay and other marks are trademarks of Google LLC.

Bluetooth trademarks are owned by Bluetooth SIG, Inc., U.S.A. and licensed to Honeywell.

Other product names or marks mentioned in this document may be trademarks or registered trademarks of other companies and are the property of their respective owners.

Patents

For patent information, refer to www.hsmpats.com.

TABLE OF CONTENTS

| | |
|--|----------|
| Customer Support | ix |
| Technical Assistance | ix |
| Product Service and Repair | ix |
| Limited Warranty | ix |
| Chapter 1 - About the Computer Features..... | 1 |
| About the Mobile Computer..... | 1 |
| CT40 Model Overview | 2 |
| CT40 XP Model Overview | 3 |
| Features of the CT40 | 4 |
| Features of the CT40 XP | 6 |
| About the Battery | 7 |
| Battery Identification | 8 |
| Battery Recommendations and Safety Precautions | 8 |
| Safety..... | 9 |
| Use and Storage..... | 10 |
| Charge the Battery Before Use..... | 11 |
| Battery Replacement..... | 11 |
| Change the Battery | 12 |
| About the Battery Status..... | 14 |
| About the Battery Status LED Setting..... | 15 |
| Check the Battery Level, Health and Usage..... | 16 |
| Power On the Computer | 17 |
| Welcome Screen..... | 17 |
| Unlock the Screen | 17 |

| | |
|---|----|
| Change the Screen Lock to Protect the Computer..... | 18 |
| Select a Touch Screen Profile to Optimize Performance | 18 |
| Configure the Screen Backlight..... | 19 |
| About the Good Read LED | 19 |
| About the Audio Features | 20 |
| Adjust Speaker Volume | 20 |
| Enable Vibrate Mode..... | 20 |
| Audio Settings | 21 |
| Insert a microSD Card..... | 22 |
| How to Transfer Files | 23 |
| Configure USB Connection and Transfer Files | 24 |
| Accessories for the Computer..... | 24 |

Chapter 2 - About the User Interface and Applications 27

| | |
|--|----|
| About the User Interface..... | 27 |
| Navigation and Function Buttons | 28 |
| About Status Bar Icons | 29 |
| Remap a Button | 30 |
| Restore Default Button Action | 31 |
| View and Manage Notifications | 31 |
| Open Quick Settings | 31 |
| Customize the Home Screen | 32 |
| Customize the Favorites Tray | 32 |
| Use Google Search | 32 |
| About Screen Gestures | 33 |
| Set the Time Zone..... | 33 |
| About Honeywell Applications..... | 34 |
| Applications You Can Download to the Mobile Computer | 35 |
| Unlock Developer Options | 37 |

Chapter 3 - Use the Imager..... 39

| | |
|------------------------------------|----|
| About the Imager | 39 |
| About the Scan Wedge Feature | 40 |

- Change the Scanner Settings40
 - Change the Bluetooth Scanner Settings41
 - Restore Default Scan Settings41
 - Default Scan Settings41
 - Add a Scan Setting Profile.....48
 - Delete a Scan Setting Profile48
- About the Optional Digital Scan Button48
 - Enable and Configure the Digital Scan Button48
- Scan Barcodes.....49
 - About Scanning Configuration Barcodes50
- Use the Scan Demo App50
 - Change the Scan Demo Symbology Settings50

Chapter 4 - Use the Phone.....53

- About the Phone53
- About the SIM Selection App.....53
- About Auto Carrier Config Selection54
- Activate the Phone.....55
- Make a Phone Call.....57
 - About Apps with Push-to-Talk Functionality.....57
- Answer the Phone57
 - Switch Apps During a Phone Call.....58
- Make an Emergency Phone Call.....58
- Configure Phone Settings58

Chapter 5 - Use the Camera59

- About the Color Camera59
- How to Zoom59
- Take a Photo60
- Record a Video.....60
- Change Camera Settings61
- Use the Camera as a Flashlight62

Chapter 6 - Configure the Computer..... 63

- How to Configure the Computer..... 63
 - Start the Settings App 63
 - About the Structure of the Settings App 63
- About Network Communications 76
 - Connect to a Wi-Fi Network 77
 - Honeywell Wi-Fi Settings 79
 - Connect to an Ethernet Network..... 79
 - How to Connect to Virtual Private Networks 79
- About Wireless Security..... 80
 - About Certificates 81
- About Bluetooth Communications 82
 - Connect a Bluetooth Device 82
 - Rename the Computer 83
 - Rename or Unpair a Paired Device..... 83
 - About the Scanner Edge App..... 84
- About Ethernet and USB Communications 85
 - USB Troubleshooting..... 86
- Bluetooth, USB, or Ethernet Tethering for Data Connection Sharing 86
 - Minimum requirements for USB Tethering 86
 - Set up and Connection 86
 - Minimum requirements for Bluetooth Tethering 86
 - Set up and Connection 87
- About Near Field Communication (NFC) 87
 - Read an NFC Tag 88
- Developer Information..... 88
- About Provisioning Mode 89
 - Enable or Disable Provisioning Mode..... 89
- About Wi-Fi Staging..... 89
 - Staging Devices 89
 - Log Files..... 93
- About Voice Wedge 93
 - Define Trigger Mode..... 94

| | |
|-----------------------------------|----|
| Associate Applications..... | 94 |
| Define Key Commands..... | 94 |
| Select Data Type..... | 95 |
| To Use Voice Wedge in an App..... | 95 |

Chapter 7 - Configure RFID Settings97

| | |
|------------------------------------|-----|
| About RFID Readers..... | 97 |
| Change the RFID Settings..... | 97 |
| Restore Default Scan Settings..... | 98 |
| Default RFID Settings..... | 98 |
| Add an RFID Profile..... | 102 |
| Delete an RFID Profile..... | 102 |

Chapter 8 - Manage and Maintain the Computer103

| | |
|--|-----|
| About Software Updates and Cyber Security..... | 103 |
| Software Downloads..... | 103 |
| About Transferring Files via USB Connection..... | 104 |
| Install Software Apps with AutoInstall..... | 104 |
| Optional microSD Card Method..... | 105 |
| About the Honeywell Upgrader..... | 105 |
| Restart (Reboot) the Computer..... | 105 |
| About an Enterprise Data Reset..... | 106 |
| Before You Begin..... | 106 |
| Enterprise Data Reset the Computer..... | 106 |
| About a Full Factory Reset..... | 107 |
| Before You Begin..... | 107 |
| Full Factory Reset the Computer..... | 107 |
| Repairs..... | 108 |
| Maintenance..... | 108 |
| Clean the Computer..... | 108 |
| About Disinfectant-ready Models..... | 108 |

Appendix A - Specifications.....109

Computer Agency Information..... 109
 Label Locations 109
Physical and Environmental Specifications 110
Imager Specifications 110
Barcode Symbologies 110
N3601 Imager Reading Distances 112
 N3601 Imager Field of View/Resolution 113
N6603 Slim Imager Reading Distances 113
 N6603 Slim Imager Field of View/Resolution 114
N6700 Imager/N6703 Ultra-Slim Imager..... 114
 N6700 Imager/N6703 Imager Field of View/Resolution..... 116
N6803-FR FlexRange Imager..... 116
 N6803-FR FlexRange Imager Field of View/Resolution 118
S0703-SR Standard Range Imager..... 118
 S0703-SR Standard Range Imager Field of View/Resolution 120

Customer Support

Technical Assistance

To search our knowledge base for a solution or to log in to the Technical Support portal and report a problem, go to honeywell.com/PSStechnicalsupport.

For our latest contact information, see sps.honeywell.com.

Product Service and Repair

Honeywell International Inc. provides service for all of its products through service centers throughout the world. Go to sps.honeywell.com and select **Support > Productivity** to find a service center near you or to get a Return Material Authorization number (RMA #) before returning a product.

For ongoing and future product quality improvement initiatives, the mobile computer comes equipped with an embedded device lifetime counter function. Honeywell may use the lifetime counter data for future statistical reliability analysis as well as ongoing quality, repair and service purposes.

Limited Warranty

For warranty information, go to sps.honeywell.com and click **Support > Productivity > Warranties**.

ABOUT THE COMPUTER FEATURES

This chapter introduces the CT40/CT40 XP mobile computer series. Use this chapter to learn about the basic computer features, functions, and accessories.

Note: *Throughout this manual, all versions of the mobile computer are referred to as the CT40/CT40 XP unless information is specific to a particular model. The device applications and settings vary by computer model and OS version. Your computer may not include all the features shown in the manual.*

About the Mobile Computer

Honeywell's CT40/CT40 XP mobile computer series, built on the Mobility Edge™ platform, delivers real-time connectivity, advanced data capture, and future-proof investment protection. All models come equipped for fast Wi-Fi connectivity with a WLAN 802.11 a/b/g/n/ac radio and Bluetooth® (v5.0) wireless technology that includes Bluetooth Low Energy support.

Wireless WWAN radio equipped models (i.e., CT40-L1N/CT40P-L1N) provide additional connectivity for high speed data and quality voice support across all network technologies. CT40/CT40 XP WWAN models also include an integrated global positioning satellite (GPS) receiver that supports GPS protocols, including Simultaneous GNSS Receiver Support for GPS, GLONASS, Galileo, and BeiDou.

The CT40 XP series offers the added benefit of an IP67 protection level and includes front and rear facing color cameras, a swap battery feature, a dedicated push-to-talk (PTT) button for common applications that support PTT, and an optional USB Type C connector (model configuration dependent). The CT40 XP series is also equipped to support Honeywell's Device Finder app when the mobile phone is registered with Operational Intelligence™.

In addition, Honeywell offers some configurations of the CT40/CT40 XP with disinfectant-ready housings that are designed to resist the effects of harsh chemicals, see [page 108](#).

To learn more about the CT40/CT40 XP series, refer to the model overview and feature sections that match your model type.

- [CT40 Model Overview](#) on page 2 and [Features of the CT40](#) on page 4
- [CT40 XP Model Overview](#) on page 3 and [Features of the CT40 XP](#) on page 6

CT40 Model Overview

| Available Feature | Model CT40-L0N | Model CT40-L1N |
|--|----------------|----------------|
| Android operating system* | x | x |
| 2.2 GHz Qualcomm Snapdragon 660 octa-core processor | x | x |
| 2GB/4 GB DDR4 RAM, 32 GB flash memory | x | x |
| Choice of Honeywell high performance 2D imager with ergonomic Scan buttons | x | x |
| WLAN IEEE 802.11 a/b/g/n/ac radio; Wi-Fi certified | x | x |
| Bluetooth™ V5.0 and Bluetooth Low Energy technology support | x | x |
| NFC technology for short-range wireless data exchange | x | x |
| Wireless WWAN radio for high speed data and quality voice support across all network technologies | | x |
| Integrated GPS receiver; GPS Supported Protocols: Simultaneous GNSS Receiver Support for GPS, GLONASS, Galileo, and BeiDou | | x |
| Mid-tier rugged specifications with IP64 sealing | x | x |
| 13-megapixel color camera, 4K video with image stabilization and advanced software features for enhanced exposure control | x | x |
| Customer-accessible microSD™ slot for removable memory cards up to 512 GB (SDXC/SDHC/SDIO-compliant) | x | x |
| Value-added software components supporting specialized imaging and OCR functions | x | x |
| Large, high definition, bright color, outdoor-readable display with responsive multi-touch capacitive touch panel** | x | x |
| Integrated ambient light sensor, proximity sensor, and accelerometer | x | x |
| Optional 3.5 mm Audio Jack (available on Wi-Fi only models) | x | |
| <p>* For information on supported Android OS versions, see the CT40 Data Sheet, available at sps.honeywell.com.</p> <p>** Use of a screen protector may have small effect on the capacitive touch panel performance.</p> | | |


Note: To learn more, see [Appendix A: Specifications](#) beginning on page 109.

CT40 XP Model Overview


| Available Feature | Model CT40P-LON | Model CT40P-L1N |
|---|-----------------|-----------------|
| Android operating system* | x | x |
| 2.2 GHz Qualcomm® Snapdragon™ 660 octa-core processor | x | x |
| 4 GB DDR4 RAM, 32 GB flash memory | x | x |
| Dedicated push-to-talk button | x | x |
| Optional Type C connector for communication/charging (available on some model configurations) | x | x |
| Swap battery feature | x | x |
| Mid-tier rugged specifications with IP67 sealing | x | x |
| 13-megapixel color camera, 4K video with image stabilization and advanced software features for enhanced exposure control | x | x |
| 8-megapixel front-facing camera | x | x |
| Choice of Honeywell high performance 2D imager with ergonomic Scan buttons | x | x |
| WLAN IEEE 802.11 a/b/g/n/ac radio; Wi-Fi certified | x | x |
| Bluetooth™ V5.0 and Bluetooth Low Energy technology support | x | x |
| NFC technology for short-range wireless data exchange | x | x |
| Wireless WWAN radio for high speed data and quality voice support across all network technologies | | x |
| Integrated GPS receiver; GPS Supported Protocols: Simultaneous GNSS Receiver Support for GPS, GLONASS, Galileo, and BeiDou | | x |
| Customer-accessible microSD™ slot for removable memory cards up to 512 GB (SDXC/SDHC/SDIO-compliant) | x | x |
| Value-added software components supporting specialized imaging and OCR functions | x | x |
| Large, high definition, bright color, outdoor-readable display with responsive multi-touch capacitive touch panel** | x | x |
| Integrated ambient light sensor, proximity sensor, and accelerometer | x | x |
| Optional 3.5 mm Audio Jack (available on Wi-Fi only models) | x | |
| <p>* For information on supported Android OS versions, see the CT40 XP Data Sheet, available at sps.honeywell.com.</p> <p>** Use of a screen protector may have small effect on the capacitive touch panel performance.</p> | | |

Note: To learn more, see [Appendix A: Specifications](#) beginning on page 109.

Features of the CT40




Note: Hand strap not shown.




* Cellular phone feature is available only on CT40-L1N WWAN models. On all models, the SIM slot supports use of an UICC card for NFC Secure Element NFC link encryption.


Note: Hand strap not shown.




Battery Latch on Models:
CT40-xxx-xxxxx0x
x = configuration variation




Battery Latch on Models:
CT40-LON-xxxxxAx
CT40-xxx-xxxxxBx
CT40-xxx-xxxxxHx
x = configuration variation




Features of the CT40 XP



Note: Hand strap not shown.



* Cellular phone feature is available only on CT40P-L1N WWAN models. On all models, the SIM slot supports use of an UICC card for NFC Secure Element NFC link encryption.



* Part of Honeywell's Device Finder solution when CT40 XP mobile phone is registered with Operational Intelligence.

About the Battery

The computer uses a rechargeable Li-ion battery as its main power source. Several factors determine the life of the battery, such as display brightness, display timeout, input device, extreme temperature, and battery usage.

CT40/CT40 XP computers are designed for use with batteries manufactured for Honeywell International Inc. See [Battery Identification](#) on page 8 for guidance on the correct battery for your unit configuration.

For a list of compatible accessories, see the *CT40/CT40 XP Accessory Guide*, available for download from the product device pages at sps.honeywell.com. Contact your local sales representative for replacement battery ordering information.



Caution: Read [Power On the Computer](#) on page 17 and all cautionary markings on the battery, charging peripheral, and device using the battery before attempting to install, use, or charge the battery.

Battery Identification

Not all batteries are the same due to computer model and/or configuration variations.

- CT40 configurations with a 0 use a battery latch and battery that is not compatible with other models.
- CT40/CT40 XP configurations with an A or B use the standard battery.
- CT40/CT40 XP configurations with a D have a disinfectant ready housing (DRH) and use a battery that is designed for DRH.
- CT40/CT40 XP configurations with an H are healthcare models and use a battery that is designed for healthcare environments.

Use the following tables to identify the appropriate battery replacement for your computer model.

| CT40 | | | |
|---|----------------------|----------------------------|--------------------------------|
| Computer x = configuration variations | Battery Model | Battery Part Number | Replacement Battery SKU |
| CT40-xxx-xxxxx0x | CT50-BTSC | 318-005-011 | 318-055-012 |
| CT40-xxx-xxxxxHx | CT50-BTSC | 318-055-H67 | 318-055-H67 |
| CT40-LON-xxxxxAx | CT50-BTSC | 318-055-067 | 318-055-067 |
| CT40-xxx-xxxxxBx | CT50-BTSC | 318-055-067 | 318-055-067 |
| CT40-xxx-xxxxxDx | CT50-BTSC | 318-055-D67 | 318-055-D67 |
| Configuration number (CN) is located on the label in the battery well of the mobile computer. | | | |

| CT40 XP | | | |
|---|----------------------|----------------------------|--------------------------------|
| Computer x = configuration variations | Battery Model | Battery Part Number | Replacement Battery SKU |
| CT40P-xxx-xxxxxHx | CT50-BTSC | 318-055-H67 | 318-055-H67 |
| CT40P-xxx-xxxxxAx | CT50-BTSC | 318-055-067 | 318-055-067 |
| CT40P-xxx-xxxxxBx | CT50-BTSC | 318-055-067 | 318-055-067 |
| CT40P-xxx-xxxxxDx | CT50-BTSC | 318-055-D67 | 318-055-D67 |
| Configuration number (CN) is located on the label in the battery well of the mobile computer. | | | |

Battery Recommendations and Safety Precautions

This section provides additional information on the safe use, handling and storage of the Lithium-ion rechargeable battery designed for use with the computer.

To learn more about Battery Maintenance for Portable Devices, go to honeywell.com/PSS-BatteryMaintenance.

Safety



Caution: Before you attempt to charge or replace the battery carefully read all labels, markings and product documentation provided in the box or online at sps.honeywell.com.



Caution: Improper battery replacement or incompatible device usage may result in risk of burns, fire, explosion, or other hazard. Dispose of lithium-ion batteries according to local regulations. Risk of fire and burns if improperly handled. Do not open, crush, heat above 60 °C (140 °F), or incinerate.



Caution: Ensure all components are dry prior to mating the computers and batteries with peripheral devices. Mating wet components may cause damage not covered by the warranty.

- Do not store the battery at temperatures above 60 °C (140 °F), such as inside a car on a hot day or in direct sunlight. Storage above 60 °C (140 °F) may damage the battery.
- Avoid dropping the battery or computer. If you suspect that the battery or computer is damaged or if intermittent power and charging issues occur, send the relevant device(s) to a Honeywell service center for inspection of the computer and/or battery. To learn more about returns, see [Product Service and Repair](#) on page ix.
- Do not use the battery if it is noticeably deformed, swollen, or discolored. Replace immediately and discard as noted in the Caution at the beginning of this Safety section.
- Do not use the battery if it is too hot to handle. Replace immediately and discard.
- Discarded batteries may create a safety hazard. Before disposal, cover the battery contacts with electrical insulating tape.
- Do not modify the battery or attempt to insert foreign objects into the battery.
- Do not solder directly to the battery contacts.
- Do not drop the battery or apply mechanical shocks or pressure to the battery.
- Do not immerse batteries into, or expose them to, water or seawater.
- Do not incinerate, microwave, throw into a fire, or expose batteries to temperatures above the maximum rating.
- Do not disassemble the battery or try to open or penetrate its housing.
- Stored batteries should be separated, not touching any other battery, device, charger, or accessory.
- Do not store or carry batteries where they are in close proximity to or touching conductive material (metal). For example, in a pocket where zippers, coins and office supplies (e.g., pens, paperclips) could also be located.

Use and Storage

When setting up the computer, you should consider how apps, services, and UI settings affect battery power consumption. Set the screen timeout feature to turn off the screen sooner and enable the Adaptive brightness feature to minimize battery use. Restrict unnecessary apps or services from running in the background to prevent battery drain. Utilize the Battery saver and Battery manager features to conserve power. Turn on Airplane mode if network connectivity is limited or is not needed.

Keep in mind that Lithium-ion battery capacity declines over time due to stress from repeated charge-discharge cycles and environmental factors such as extreme operating/storage temperatures and humidity. As the battery lifespan/health declines, the battery energy dissipates more quickly or may take longer to charge.

Remember that the battery self-discharges slowly over time, even if the computer is turned Off or the battery is stored outside the computer. Environmental factors such as extreme temperature and humidity affect self-discharge rates and can impact the battery lifespan.

Follow the recommendations below for battery use and storage.

- For maximum battery life, charge the battery at 20 °C (68 °F) to 25 °C (77 °F) and store at 20 °C (68 °F) with a 30%-50% charge.
- Use only Honeywell-approved charging methods and devices. See [Charge the Battery Before Use](#) on page 11. Use of this battery in other devices could result in damage to the device or battery.
- Replace the battery only with a Honeywell replacement battery. See [Battery Identification](#) on page 8 for guidance on the correct battery for your unit configuration. These batteries have been tested in accordance with applicable safety standards. Contact your Honeywell sales representative or distributor if this battery is no longer available.
- Batteries should be replaced periodically, typically every two years or if the battery health falls below 70% (see [Check the Battery Level, Health and Usage](#) on page 16).
- Promptly recharge the battery or replace the battery with a charged battery when you notice the battery status icon indicates the charge is low.
- Avoid allowing the battery to be completely drained since this applies stress on the battery and may shorten lifespan.
- Do not store batteries in a charger that is not connected to power.
- If you are storing the computer for a few days (e.g., over the weekend), install a fully charged battery or connect the computer to a power source.
- If you are storing the computer for longer than a few days, remove and charge the battery. When the battery is done charging, store both the battery and the computer separately in a cool and dry location. Periodically check the battery charge level. This is especially critical when storing batteries for several months.

since the battery will gradually self-discharge and a fully drained battery can impact the battery lifespan.

Charge the Battery Before Use

The mobile computer ships with a partially charged battery. Charge the battery with a CT40/CT40 XP series charging device for a minimum of **4 hours**.

Note: *Using the computer while charging the battery increases the time required to reach a full charge.*

About CT40 XP Models with USB Type C Connector

On CT40 XP model configurations with the optional USB Type C connector, you can use a USB cable to charge the mobile computer from a host device (e.g., laptop or desktop computer). The connected host device must supply a minimum power output of 5V, 1A to the CT40 XP or the battery will not charge.

Note: *If the mobile computer is drawing more current than supplied by the charging source, charging will not take place.*

Battery Replacement

If your battery power is low, you need to either charge the battery in the computer or replace it with a charged battery. (See also [Check the Battery Level, Health and Usage](#) on page 16.)

Before Attempting to Remove the Battery

Always do the following before removing the battery:

- If you have a CT40 model, power Off the computer.
- If you have a CT40 XP model, place the unit in Swap Battery mode (see below).

CT40 XP Swap Battery Mode

Swap Battery mode places the computer in a lower power state so that the battery can be removed for a short time. This feature is not available on CT40 models.

To activate Swap Battery mode:

1. Press and hold the **Power** button until the options menu appears.
2. Touch **Swap Battery** and follow the on-screen instructions.
3. Once you replace the battery, press the **Power** button.

Change the Battery




Warning: Improper battery replacement or incompatible device usage may result in risk of burns, fire, explosion, or other hazard. Dispose of lithium-ion batteries according to local regulations. Risk of fire and burns if improperly handled. Do not open, crush, heat above 60°C (140°F), or incinerate.


If your battery power is low, you need to either charge the battery in the computer, or replace it with a charged battery.

Remove the battery


1. Depending on the model type, either power Off the computer or place it in Swap Battery mode. See [Before Attempting to Remove the Battery](#) on page 11.
2. Release the hand strap.




3. Unlock the battery.
 - For the model CT40-xxx-xxxxx0x, press and hold down the small button on the battery latch, and then slide the latch toward the right side of the computer to unlock the battery.



- For all CT40 XP models and CT40-LON-xxxxxAx, CT40-xxx-xxxxxBx, and CT40-xxx-xxxxHx models, press and hold down the small button on the battery latch, and then slide the latch toward the right side of the computer. The battery will pop-up slightly on the edge when latch is released.




4. Lift up on the edge of the battery and remove it from the computer.



Install the Battery



1. Insert the charged battery into the computer. See [Battery Identification](#) on page 8.





2. Verify the battery latch is in the Locked position.

Model CT40-xxx-xxxxx0x:
Slide the battery latch
toward the left side of the
computer to engage the
lock.

Models:
CT40-LON-xxxxxAx,
CT40-xxx-xxxxxBx,
CT40-xxx-xxxxxHx, and
all CT40 XP




3. Attach the hand strap.









4. Press the **Power** button.

About the Battery Status

Use the battery icon in the Status bar at the top of the screen to see the charge level of your battery. If you want more detailed information on your battery, such as usage time, charge remaining on the battery, or battery health information, open the **Settings** app  and tap **Battery**.


Battery Status Icons

| Icon | Status |
|---|--------------------------------|
|  | The battery charge is at 100%. |

| Icon | Status |
|---|---|
|  | The battery charge is at 50%. |
|  | The battery charge is low. You need to charge or replace the battery soon. |
|  | The battery is critically low. You need to replace the battery now or connect the computer to a charging accessory. |
|  | The computer is connected to external power and the battery is charging. |
|  | There is a battery error. Install another battery. If the problem persists, call Honeywell Technical Support. |

The Battery status LED color and behavior (e.g., steady on, blinking, or off) indicates the charging status of the battery. To view status descriptions and to learn how to modify the Battery LED behavior, see [About the Battery Status LED Setting](#) on page 15.

Battery Status LED



About the Battery Status LED Setting

You can change the behavior of the Battery status LED if the out-of-box behavior for a charging battery (blinking green) is not acceptable to your environment.

You can choose one of three options:

- **Default Battery LED** (optional Android OS configuration)
- **Honeywell Battery LED** (factory default, out-of-box configuration)
- **No Battery LED**
- **Mix Mode**

Honeywell Battery LED Behavior (Factory Default/Out-of-Box Configuration)

| Connected to Power | LED State | Description |
|--------------------|----------------|--------------------------------------|
| No | Blinking amber | Battery level is below 15% |
| No | Off | Battery level is more than 15% |
| Yes | Steady amber | Battery level is between 0% and 60% |
| Yes | Blinking green | Battery level is between 60% and 95% |
| Yes | Steady green | Battery level is above 95% |
| Either | Blinking red | Battery error |


Default Battery LED Behavior (Optional Android OS Configuration)

| Connected to Power | LED State | Description |
|--------------------|--------------|--------------------------------------|
| No | Blinking red | Battery level is below 15% |
| No | Off | Battery level is 15% or more |
| Yes | Steady red | Battery level is below 15% |
| Yes | Steady amber | Battery level is between 15% and 90% |
| Yes | Steady green | Battery level is 90% or more |

Select the No battery LED setting if you want to use the LED as a notification LED for applications or device management solutions. For more information on how to use the LED as a notification LED, see <http://developer.android.com/guide/topics/ui/notifiers/notifications.html>.



Change the Battery Status LED Behavior

To change the battery status LED behavior:

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Battery LED**.
3. Choose one of the options:
 - **Default Battery LED** (optional Android OS configuration)
 - **Honeywell Battery LED** (factory default, out-of-box configuration)
 - **No Battery LED**
 - **Mix Mode**

Check the Battery Level, Health and Usage

In addition to the Battery status icon and LED, you can use one of the following methods to monitor the battery status.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Select one of the following:
 - **Settings**  > **Battery**
The current percentage of battery power remaining and the amount of usage time left on the battery appear on the screen. You can also access the **Battery saver** feature from the battery screen.
 - **Settings**  > **Honeywell Settings** > **Battery Optimizer**
View battery status, health and app usage information. Create and enable or

disable a battery optimization profile that implements a group of settings to conserve power.

- **Power Tools > BattMon**
Refer to the Power Tools user guide available at sps.honeywell.com for more information.

Power On the Computer

After you have fully charged and installed a battery, power On the computer for the first time:

- Press and hold the **Power** button for approximately 3 seconds, and then release the button.

Welcome Screen

The first time you power On the computer, a Welcome screen appears. You can either scan a configuration barcode or use the Wizard to manually set up the computer. To learn more about how to [Scan Barcodes](#), see [page 49](#). To learn more about configuring multiple devices using Wi-Fi Staging app, see [page 89](#).

During the manual setup process, follow the prompts on the screen as the wizard has you:

- Set the default language.
- Set up the Wi-Fi network connections.
- Set the time, date, and time zone.
- Personalize (name) the computer.
- Set up security and privacy options.

Once you complete the initial setup, the Welcome screen no longer appears when you power On the computer and **Provisioning Mode** is automatically turned Off (disabled). Scanning a barcode to install applications, certificates, configuration files, and licenses on the computer is restricted when **Provisioning Mode** is turned Off. To learn more [About Provisioning Mode](#) see [page 89](#).

Unlock the Screen

The screen lock automatically activates every time the computer is turned On or when the computer wakes from sleep mode.


- Swipe up from the lock icon at the bottom of the screen.

The level of security provided depends on the type of lock set (e.g., Swipe, Pattern, PIN, or Password). The default setting (Swipe) provides no protection against unauthorized access to your computer.

Change the Screen Lock to Protect the Computer

After you start using the computer, you should change the screen lock to prevent unauthorized persons from accessing the computer after the screen lock activates, unless they input the correct password, PIN, or pattern.

The recommended setting for the Screen Lock is to enable a Password lock. Use a strong password value (e.g., include numbers, characters, special characters, and mixed character case).

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Security** > **Screen lock**.
3. Choose one of the following options:
 - **None**
 - **Swipe**
 - **Pattern**
 - **PIN**
 - **Password**
4. Follow the on-screen prompts to complete the setup.
5. Exit the Settings app.

Select a Touch Screen Profile to Optimize Performance


Optimize screen interactions by selecting a touch screen profile designed specifically for your use case. For example, if you wear gloves, set the touch screen profile to Glove enhance mode for the best touch screen response.

Note: *Maximum glove thickness of 2 mm (0.08 inches) for touch screen response.*

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings** > **Honeywell Settings** > **Touch Screen Profile**.
3. Choose one of the following options:
 - **Normal mode**
 - **Finger enhance mode**
 - **Glove enhance mode**
 - **Stylus enhance mode**
 - **Protector mode**
4. Exit the Settings app.


Configure the Screen Backlight

The display has an ambient light sensor that automatically adjusts the backlight intensity to conserve power and ensure the display is readable. You can also manually set the backlight intensity if you do not want to use the automated adaptive brightness feature.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Display**.
3. Choose one of the following options:
 - To have the computer automatically adjust the brightness for your work environment, turn On the **Adaptive brightness** setting. You can tap **Adaptive brightness** to toggle the feature On or Off.
 - To set the brightness level manually, verify the Adaptive brightness feature is turned Off, and tap **Brightness level**. Adjust the slider to set the brightness level.

About the Good Read LED

The Scan Status LED indicates the read status of the imager when scanning a barcode. When active, the LED illuminates the outer ring of the front speaker. To learn more about how to use and configure the imager for scanning, see [Chapter 3: Use the Imager](#) beginning on page 39.



Good Read LED Descriptions

| LED Color | Description |
|----------------|--|
| Green | Good read of a barcode. |
| Blinking green | The data collection imager is processing or starting up. |
| Red | Failure to scan barcode. Check to make sure you have the correct symbology enabled. |

About the Audio Features

The CT40 has multiple speakers, a microphone, and several software tools to configure sound volume or enable vibration feedback.

Adjust Speaker Volume




Use the Volume button on the left side of the computer to adjust the volume of ringtones, media, notifications, and alarms.

Note: *The volume setting varies by OS version.*

To quickly change the active speaker volume level:

- Press the top of the Volume button (+) to raise the volume of the active speaker.
- Press the bottom of the Volume button (-) to lower the volume of the active speaker.

To access the volume quick set menu:


1. Press the center of the Volume button.
2. Adjust the volume level using the on-screen menu.
 - Tap the icon at the top to toggle the media volume between sound On , vibrate only , and silent .
 - Use the slider to adjust the media volume.
 - Select ●●● at the bottom to adjust Media, Call, Ring, or Alarm volume levels.

Enable Vibrate Mode

Simultaneously press the **Volume up** (+) and **Power** button to quickly enable Vibrate mode so the computer vibrates instead of emitting sound for notifications and rings.

If you need quiet time without interruptions, enable Do Not Disturb to mute sound, stop vibration, and block notifications. Under the full settings menu, you can set a schedule for when you want Do Not Disturb to automatically turn On and Off.

To enable Do Not Disturb manually:

1. Swipe down from the top of the screen to view quick set menu.
2. Tap the **Do Not Disturb** icon  to toggle the feature On/Off.

Audio Settings

This section describes the audio and sound settings you can configure in the Settings app.

- To change audio settings, open the **Settings** app  and tap **Sound & vibration**.

Sound & Vibration Settings


| Setting | Description |
|-----------------------------|---|
| Media volume | Use the sliders to set the volume for media (e.g., music, videos, and games), calls, alarms, and rings (notifications and ringtones). |
| Call volume | |
| Ring & notification volume | |
| Scanbeep volume | |
| Alarm volume | |
| Do not disturb | Select to set which notifications to let through when you have Do Not Disturb turned On and when you want to be left alone. |
| Phone ringtone | Select a default ringtone. |
| Media | Select to show or hide media player when the media session has ended. |
| Vibration & haptics | Enable and manage vibration and haptics features. <ul style="list-style-type: none"> • Turn Vibration and haptics On or Off. • Configure ring vibration for calls. • Turn Notification and Alarm vibration On or Off. • Turn Touch feedback On or Off. • Turn Media vibration On or Off. |
| Shortcut to prevent ringing | Set what happens when you simultaneously press the Power and Volume up button. Options include: Vibrate, Mute, or turn the shortcut Off. |
| Default notification sound | Select a notification sound. |
| Default alarm sound | Select an alarm sound. |
| Other sounds and vibrations | Turn sounds On or Off for: <ul style="list-style-type: none"> • Dial pad tones • Screen locking sounds • Charging sounds and vibration • Touch sounds • Touch vibration • Always show icon when in vibrate mode |

Insert a microSD Card


You can use a microSD card to increase file storage capacity or to install software. Honeywell recommends the use of Single Level Cell (SLC) industrial grade microSD or microSDHC memory cards with the computer for maximum performance and durability.

Note: *Format the memory card before initial use.*


1. Save your files and close any open applications.
2. Press and hold the **Power** button until the options menu appears.
3. Tap **Power off**.
4. Remove the battery from the computer (see [page 12](#)).
5. Lift up the edge of the SD card access door.




6. Press down gently and slide the card holder toward the open access door. Lift the edge of the holder up.




7. Insert the microSD card into the card holder with the contacts facing out.



8. Close the holder with the card inserted. Press down gently on the card holder and slide it into the locked position.



9. Close the SD card access door.



10. Install the battery (see [page 13](#)).

How to Transfer Files

To transfer files, you can physically connect the mobile computer to your workstation (e.g., laptop or desktop computer) through a USB connection. When the mobile computer is connected and USB is configured for file or photo transfer, use a file browser (e.g., File Explorer or Windows Explorer) on your workstation to

transfer files between the two computers. If you are transferring files to and from a Mac, use the Android File Transfer application (available from www.android.com/filetransfer).

Note: File transfer through a USB connection is disabled by default. You need to configure the USB connection for transferring files or photos.

You can use these accessories to connect your mobile computer to your workstation:

- Home Base or Ethernet Home Base, and a standard USB Type B to A cable.
- Snap-On Adapter, Tethered USB Cable Client (CT40-SN-USB-0).
- For CT40 XP models with the optional Type C USB port, a standard USB cable with Type C connector.

Configure USB Connection and Transfer Files

Note: The CT40/CT40 XP supports Hi-Speed USB communications (USB 2.0) with a maximum data transfer rate of 480 Mbps.

1. Connect the CT40/CT40 XP to your workstation.
2. On the CT40/CT40 XP, swipe down from the top of the screen to see the notifications.
3. Tap the **Android System** notification twice to open the options menu.
4. Select either **File Transfer** or **PTP**.
5. Open the file browser on your workstation.
6. Browse to the mobile computer. You can now copy, delete, or move files between the CT40/CT40 XP and your workstation.

Accessories for the Computer

The CT40/CT40 XP ships with a battery and hand strap. All other accessories are ordered and shipped separately.

For a complete list of compatible accessories for your mobile computer and their part numbers, see the CT40/CT40 XP *Accessory Guide* available for download at sps.honeywell.com.

Contact your local sales representative for ordering information.

| Accessory | Part Number | Use With |
|--|-------------|----------|
| * Requires protective boot (i.e., CT40-PB-00 or CT40-PB-XP) for use on mobile computer. ** Not compatible with protective boot (i.e., CT40-PB-00 or CT40-PB-XP). x = Kit variations. See Product Accessory Guide at sps.honeywell.com for additional details. | | |
| CT40 Protective Boot | CT40-PB-00 | CT40 |

| Accessory | Part Number | Use With |
|---|---|----------------------------|
| <p>* Requires protective boot (i.e., CT40-PB-00 or CT40-PB-XP) for use on mobile computer. ** Not compatible with protective boot (i.e., CT40-PB-00 or CT40-PB-XP). x = Kit variations. See Product Accessory Guide at sps.honeywell.com for additional details.</p> | | |
| Universal CT40/CT40 XP Protective Boot | CT40-PB-XP | CT40/CT40 XP |
| Ethernet Home Base: Charge/communication base for one mobile computer and one spare battery. Base has one Ethernet connector and one USB client connector (Type B). | CT40-EB-x ** | CT40/CT40 XP |
| | CT40-EB-PB-x * | |
| | CT40-EB-UVB-x ** | |
| Home Base: Charge/communication base for one mobile computer and one spare battery. Base has one USB client connector (Type B). | CT40-HB-x ** | CT40/CT40 XP |
| | CT40-HB-UVB-x * | |
| Display Dock: Dock for connecting one mobile computer to an external display. Extends I/O for HDMI, Ethernet communications, and includes three USB ports. | CT40-DB-x ** | CT40/CT40 XP |
| | CT40-DB-UVB-x * | |
| Charge Base: Base charges up to four mobile computers. | CT40-CB-CNV-x ** | CT40/CT40 XP |
| | CT40-CB-PB-x * | |
| | CT40-CB-UVB-x * | |
| Ethernet (Net) Base: Base holds four mobile computers and is both a charge and communication base with two RJ45 Ethernet ports. | CT40-NB-CNV-x ** | CT40/CT40 XP |
| | CT40-NB-PB-x * | |
| | CT40-NB-UVB-x * | |
| Snap-on Cup: Tethered USB adapter charges one mobile computer and allows data transfer via USB client connectivity. CT40-SN-CNV-x includes adapter for mobile computer use with or without protective boot. | CT40-SN-USB-x ** | CT40/CT40 XP |
| | CT40-SN-CNV-x | |
| Scan Handle: Scan handle attaches to the mobile computer to provide handle grip and pull-trigger for barcode scanning. CT40-SH-CC** provides rear camera clearance. | CT40-SH-CC ** | CT40/CT40 XP |
| | CT40-SH-DC ** | |
| | CT40-SH-PB * | |
| Vehicle Dock: Vehicle Dock with hard-wired 3-pin power cable. CT40-VD-CNV-x includes adapter for mobile computer use with or without protective boot. | CT40-VD-x** | CT40/CT40 XP |
| | CT40-VD-CNV-x | |
| Holster: Holster is belt clip. Holds one mobile computer. | 825-238-001** | CT40 |
| Battery | See Battery Identification on page 8. | CT40/CT40 XP |
| Quad Charger: Charges up to four CT40/CT40 XP batteries. See Battery Identification on page 8. | CT40-QBC-x | CT40/CT40 XP battery packs |


ABOUT THE USER INTERFACE AND APPLICATIONS

Use this chapter to learn about the user interface and how to interact with the screen. You can also use this chapter to learn about the Honeywell applications on the computer.

Note: Screen content and features may vary by computer model and OS version.

About the User Interface

The Android operating system provides a touch-friendly and easy-to-navigate user interface. When you turn on the mobile computer, the Home screen is the first screen that appears after language provisioning and the startup wizard is complete.



Home Screen Features

| Item | Description |
|----------------------------------|---|
| Notifications panel / Status bar | Status icons to the left tell you when an app has sent notifications, such as an arriving message. System icons to the right display the current wireless and network connection state and battery level. |
| Search bar | Search the Internet or the computer using Google. Tap the microphone icon in the search box to initiate a voice search or command. |
| Home Screen panel | You can create more than one custom Home screen panel. Swipe left or right on the Home to switch between your custom panels. |
| Favorites tray | App icons in the customizable tray are visible on all Home screen panels. |

Navigation and Function Buttons








Your mobile computer has virtual buttons on the front panel below the Favorites tray and hardware buttons located on the sides for easy navigation and quick feature access when using the computer.


For button locations, see:

- [Features of the CT40](#) on page 4
- [Features of the CT40 XP](#) on page 6

To learn how to [Remap a Button](#), see [page 30](#).

Navigation and Function Button

















| Button | Description | |
|---|--------------|--|
|  | Back | Tap to return to the previous screen. |
|  | Home | Tap to return to the Home screen. |
|  | Recent Apps | Tap to view and switch between recently used apps. |
|  | Scan | Tap the front (on-screen) Scan button to trigger the scanner. |
|  | Volume | Press the top of the Volume button to raise the speaker volume. Press the bottom of the Volume button to lower the speaker volume. |
|  | Scan | Press the right or left Scan button to trigger the scanner. |
|  | Push-to-Talk | Dedicated Push-to-Talk button on CT40 XP models only. See About Apps with Push-to-Talk Functionality on page 57. |

| Button | Description | |
|---|-------------|---|
|  | Power | <p>Press and release the Power button to activate or exit sleep mode (see Screen timeout on page 68).</p> <p>Press the button for approximately 3 seconds and then release to view the options menu.</p> <ul style="list-style-type: none"> • Power off (see page 17) • Restart • Swap Battery (CT40 XP models only, see page 11) • Emergency <p>Perform a manual restart if touchscreen is unresponsive (see page 105).</p> |

About Status Bar Icons

Status and notification icons show you the current status of your network, the battery, notifications, and sounds. Use the table below to understand some of the most common icons.


Status and Notification Icons

| Icon | Description | Icon | Description |
|---|---|---|--|
|  | Pending alarm and alarm is set. |  | Vibrate mode is turned On. |
|  | New text message or multimedia message. |  | Airplane mode is turned On. |
|  | Error with text or multimedia message delivery. |  | Bluetooth is turned On. |
|  | New email. |  | SD card is full. |
|  | Computer is connected to a PC with a USB cable. |  | Wi-Fi network connected with full signal strength. |
|  | Synchronizing data. |  | Wi-Fi network connected but no signal strength. |
|  | Error with sync or sign-in. |  | Phone connected with full amount of bars. |
|  | Computer is connected with Ethernet. |  | Phone connected with full amount of bars but no Internet connection. |

Remap a Button

You can change the default function of the Left Scan, Right Scan, Volume Up, and Volume Down buttons as well as the Back, Home, and Recent virtual buttons.

Note: *The Push-to-Talk button on CT40 XP models cannot be remapped.*

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Keyremap**.
3. Tap the plus sign (+).
4. Press the button you want to remap or select one of the virtual buttons.
5. Tap **OK**.
6. Select one of the following options:
 - Tap **Keys** to view available functions. Select the function you want assigned to the button.
 - Tap **Apps** to view available applications. Select the application you want assigned to the button.
 - Tap **Actions** to enter an Intent or Broadcast. Tap **OK** to assign the action to the button. For example, to start an Intent, type `com.android.settings/com.android.settings.wifi.WifiSettings`.
 - Tap **Command** to enter a command that will be executed when the button is pressed. This option supports all ADB shell commands. For example, if you choose a button to remap and enter the command “input keyevent 64”, pressing the selected button will open the web browser on the device.
 - Tap **Text** to type characters to display when the remapped key is pressed. Use a comma “,” to separate the characters. Tap **OK** to assign the text to the button. Examples are listed below:



| Input Text | Button Press |
|---|--------------|
| A,A,B | aab |
| SHIFT_LEFT,A,SHIFT_LEFT,B or CAPS_LOCK,A,CAPS_LOCK,B | AB |
| SHIFT_LEFT,1 | ! |
| CTRL_LEFT,A | (Select All) |
| VOLUME_UP | (Volume Up) |

Note: *Lower case text is not supported in the **Text** field. Text must be entered in upper case. For example, “H,e,l,l,o” will display as “h”, whereas “H.E.L.L.O” will display as “hello”.*

7. Tap **Keys** or **Applications** to view the available functions.
8. The function you selected now appears next to the button name.

Restore Default Button Action


To restore the button default action:

1. Swipe up from the bottom of the Home screen to access all apps.
 2. Tap **Settings**  > **Honeywell Settings** > **Keyremap**.
 3. Tap the clean icon .
 4. Choose the remapped button(s) you want restored to the default setting.
 - Tap the check box next to the button.
- OR
- Tap **All Select** to choose all the buttons.
 5. Tap **Delete**.

View and Manage Notifications

You can view recent events on the computer, manage system notifications, change a setting, or quickly respond to an app notification by opening the notifications panel.

When a notification icon appears in the status bar at the top of the screen:

1. Swipe down from the top of the screen to open the notifications panel.
2. Respond to the notification. You can take one of the following actions:
 - Tap the notification to open the associated app.
 - Tap a quick-reply or action command (e.g., Reply, Archive) if available.
 - Swipe the notification sideways, off the screen to dismiss it. Note that some notifications cannot be dismissed.
 - Slide the notification left or right to reveal the settings icon . Choose between **Stop notifications** or **Keep showing**.

To close the notification panel, swipe up from the bottom of the screen, or tap the **Back** or **Home** buttons.

Open Quick Settings

Use the Quick Settings screen to quickly access common settings. Tap an icon to toggle the feature On/Off or to open additional settings.

- To open Quick Settings, swipe down twice from the status bar at the top of the screen.
- To close Quick Settings, tap the top of the screen, or tap the **Back** or **Home** buttons.

Customize the Home Screen

You can add application icons to any Home screen for easier access.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap and hold the app you want to add. The computer vibrates and then switches to a smaller view of the Home screen panels.
3. Drag and drop the app icon into place.
 - If you want to add another Home screen, drag the icon to the right edge of the screen before releasing the icon.
 - If you want to create a folder, drag and drop the icon on top of another icon.

To add widgets or customize the look of the Home screen:

1. Tap and hold an empty section of the Home screen.
2. Select either **Wallpaper & style**, **Widgets**, or **Home settings**.

Customize the Favorites Tray

Modify the Favorites tray to contain the apps you use the most.

1. Tap and hold the app icon you want to replace on the Favorites tray.
2. Drag and drop the app on “**X Remove**” at the top of the screen.
3. Swipe up from the bottom of the screen to access all apps.
4. Tap and hold the icon of the app you want to add.
5. Drag and drop the icon into position on the Favorites tray.

Use Google Search

Use the Google Search field on the Home screen to help you find anything you need on the computer or on the web.

1. On the Home screen, tap inside the Google Search box and begin to type your search term.

As you type, suggestions from Google web search appear below the Search box, and results from the computer (such as apps or contacts) appear below the web search results.
2. Tap a suggestion to search for it immediately, or tap the arrow to add the term to the search field without starting to search.

About Screen Gestures

Use your fingers or the stylus to manipulate icons, buttons, menus, the on-screen keyboard, and other items on the screen.

- **Tap**

Tap to select something, toggle a setting On or Off, or activate a field for text entry. An on-screen keyboard automatically appears for text entry.

- **Tap and hold**

Tap and hold an item but do not lift your finger or stylus until an action occurs.

- **Drag and drop**

Tap and hold an item, and then slide your stylus or finger across the screen until you reach the target position. Lift your finger or stylus off the screen to drop the item in place.

- **Swipe**

Quickly move your finger across the screen, without pausing when you first touch the screen. For example, you can swipe a Home screen left or right to view the other Home screens.

- **Slide**

Slowly move your finger across the screen, without pausing when you first touch the screen. For example, you can slide a notification to the left until the Settings gear is revealed.

- **Double-tap**


Tap quickly twice on a web page, map, or other screen to zoom in. Double-tap again to zoom out.

- **Pinch**

In some apps, you can zoom in and out by placing two fingers on the screen at once and pinching them together (to zoom out) or spreading them apart (to zoom in).

Set the Time Zone

The computer gets the current date and time from its network connection. If preferred, you can change this behavior and manually set the time zone for your location.








1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **System** > **Date & time**.
3. To change the time, tap **Set time automatically** to turn Off the feature.









- a. Tap **Date** then select a date from the calendar and click **OK**.
 - b. Tap **Time** then use the clock to select a new time and click **OK**.
4. To change the time zone, tap **Use location to set time zone** to turn Off the feature.
 - a. Tap **Time zone** and choose the time zone for your location.

About Honeywell Applications

Honeywell applications help you troubleshoot and connect your computer to other devices and networks. Some of the applications in this table are located in the Power Tools app. To learn more about Honeywell Power Tools, go to sps.honeywell.com and download the *Power Tools User Guide*.

Honeywell Applications Available on the Computer

| Icon | Application | Description |
|---|----------------------|--|
|  | AutoInstall Settings | Enable the AutoInstall feature, to automatically install *.zip or *.apk files containing applications saved in the Internal shared storage\honeywell\autoinstall folder and IPSCM card\honeywell\autoinstall folder on the computer during the power-up boot or reboot process. |
|  | Demos | Honeywell Demo apps demonstrate the basic capabilities of the computer and are not intended as functional business solutions. The demos included demonstrate scanning, signature capture, NFC functionality, and printing via Bluetooth technology. Information on how to create custom applications for your Honeywell mobile computer can be found in the Honeywell Software Development Kit (SDK) for Android, available from the Technical Support Downloads Portal . |
|  | HUpgrader | Use the Honeywell Upgrader app (HUpgrader) to automatically search for and install Over-the-Air (OTA) operating system updates from a remote server. |
|  | RFID | Use the RFID Discovery app to pair a Honeywell mobile device with a Honeywell RFID reader. |
|  | Scanner Edge | Use the application to: <ul style="list-style-type: none"> • View connected devices. • Pair with a Bluetooth Scanner. • Disconnect a Bluetooth Scanner. |
|  | SIM Selection | The SIM Selection app only appears on CT40-L1N/CT40P-L1N models equipped with dual SIM slots. Use the SIM Selection app to configure and switch between two SIM cards installed in the computer. |
|  | Staging Hub Agent | View information related to the Op Intel agent. For more information on Operational Intelligence, go to sps.honeywell.com . |

| Icon | Application | Description |
|---|------------------------|---|
| Power Tools | | |
|  | BattMon | BattMon provides information on the charge status and health of the battery, and provides access to activate battery status notifications and battery charging history logs. |
|  | ConfigApps | The ConfigApps Power Tool gives you the ability to enable or disable apps installed on the computer and to uninstall app updates that may be causing storage or performance issues. You can also view the total number of apps on the computer and the total number of apps currently disabled. |
|  | Configure Autorun | Configure Autorun provides the ability to set applications to automatically run after a reboot. |
|  | Diagnostic Information | Diagnostic Information provides access to system statistics, notifications, and version information about the computer. |
|  | EZConfig | EZConfig supports advanced customization and configuration of the hand held computer. EZConfig includes a standard XML editor and configuration barcode scanner feature. |
|  | OBDQuickLink | Use Honeywell OBDQuickLink to write, erase, or update the NFC connection between the CT40/CT40 XP computer and the CT40/CT40 XP Vehicle Dock. This app does not receive any data from the On-Board Diagnostics (OBD) system adapter. Refer to CT40/CT40 XP Vehicle Dock Quick Start Guide for more information. |
|  | WiFi Diagnostic | Use the application to: <ul style="list-style-type: none"> • View Wi-Fi radio status information about a connected access point or a list of other available access points in range of the Wi-Fi radio. • Use the Route utility to view packet destination gateway information across the subnets. • Use the IPConfig utility to view IP parameters for the on-board network adapters. • Use the Ping utility to verify communication links or to make sure a specific IP address is working. |
|  | Wireless Tether | Use to enable range tracking and customize out-of-range alerts for Bluetooth devices paired and tethered to your hand held computer. |

Applications You Can Download to the Mobile Computer

You can download Honeywell applications to extend the capabilities of the computer. You may need to purchase an license to run some applications. To learn more about the applications described in this section and other Honeywell software solutions, go to sps.honeywell.com > Software > Productivity.

About Honeywell Enterprise Browser

Honeywell Enterprise Browser is a locked-down enterprise Web client application designed for Honeywell computers. It provides a controlled Web application environment that helps enterprises increase productivity and reduce IT management expenses. You can configure Enterprise Browser for your specific application requirements and design custom web applications that run through the Enterprise Browser to provide your users with an easy-to-use yet controlled experience.

If Enterprise Browser is not included on your computer model, you can download a trial version for evaluation. After the evaluation period expires, you need to purchase a license. For more information about Enterprise Browser, visit sps.honeywell.com.

About Terminal Emulators

Honeywell offers several terminal emulator solutions that allow users to manage their mobile devices by providing reliable data transfer between the host mobile device and terminal. Terminal emulators can be used for remote management and configuration of devices, data collection and analysis, and session management.

Depending on the computer model, a terminal emulator may come pre-installed on the device. If a terminal emulator is not included on your model, you can download a trial version for evaluation. After the evaluation period expires, you need to purchase a license. For more information, visit sps.honeywell.com.

About Honeywell Launcher

Launcher is a configurable locked-down menu program designed for Honeywell computers that prevents end-users from accessing the start menu and other non-authorized applications. Use Launcher to provide a platform where your mobile computer users are limited to running only company-approved applications and prevent them from initiating unauthorized configuration changes. You can also use Honeywell Launcher together with Honeywell Enterprise Browser to create a single-purpose device configuration.

If Launcher is not included on your computer model, you can download a trial version of the software for evaluation. After the evaluation period expires, you need to purchase a license. For more information about Launcher, visit sps.honeywell.com.



About UEMConnect

Honeywell UEMConnect makes use of the Google OEMConfig protocol by providing standardized development for EMMs and giving access to Honeywell propriety features. EMMs making use of Google OEMConfig and Honeywell UEMConnect are enabled to provide access to Honeywell proprietary features via the EMM console.

For more information about OEMConfig, see support.google.com/work/android/answer/9388447?hl.

Unlock Developer Options

Developer options only appear in the Settings app if you unlock the feature. If you are a developer working with the computer, you can easily unlock the additional settings to use for testing and debugging applications under development for the computer.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **About phone**.
3. Tap **Build number** seven times. A message appears informing you that you are now a developer.
4. Open **Settings**  > **System** and scroll to the bottom of the list.
5. Tap **Developer options**.

USE THE IMAGER

Use this chapter to understand how to scan barcodes, configure the scan settings, and capture images using the integrated image in the computer.

About the Imager

The CT40 series high-performance imager options:

- N3601 Imager
- N6603 Slim Imager
- N6703 Ultra-Slim Imager
- N6803-FR FlexRange™ Imager
- S0703-SR Standard Range Imager

The CT40 XP series high-performance imager options:

- N6700 Imager
- N6703 Ultra-Slim Imager
- N6803-FR FlexRange Imager
- S0703-SR Standard Range Imager

You can use the imager in the computer as a scanner or camera.

- Use the imager as a scanner to read 1D and 2D barcode symbologies, composite symbologies, and postal codes. It also supports omni-directional scanning for greater flexibility in real-world settings. By default, the scanner feature is enabled and uses the default scan profile. You can modify the **Default Profile** or create new profiles for custom applications from the **Settings > Honeywell Settings > Scanning**.
- Use the imager as a camera to capture black and white images, such as signatures or pictures of damaged inventory. The imager camera feature requires the development of a custom application that uses the Honeywell

Mobility SDK for Android. To download the Honeywell Mobility SDK for Android, see [Developer Information](#) on page 88.

Note: *Instead of using the internal imager, you can also use Bluetooth communications to connect the computer to an external scanner, such as the Granit™ 1990i and 1991i.*


About the Scan Wedge Feature

The scan wedge feature sends scanned barcode data to an active application as Android keypad input. To scan a barcode as keyboard input, open an application that accepts text input and then scan a barcode. You can use applications that are coded to use the scanner or applications that receive data through the scan wedge feature. If an application claims the scanner through the BarcodeReader API, the scan wedge feature is temporarily disabled.

You can find information on how to create custom applications for the computer in the *Software Development Kit (SDK)* available for download from the *Technical Support Downloads Portal* at honeywell.com/PSSsoftware-downloads. Once you create an account and enter the portal, navigate to **Software > Software and Tools > Developer Library > SDKs for Android**.

Change the Scanner Settings


Changes you make to the Default profile apply to all applications with no profile assigned.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Scanning**.
3. Tap **Internal Scanner** > **Default profile**.
4. Select from the following:
 - **Data Processing Settings**,
 - **Symbology Settings**,
 - **Decode Settings**,
 - **Imager Settings**,
 - **Trigger Settings**, or
 - **Notification Settings**.
5. Modify the settings to meet your application needs.

To learn more about the scanner settings, see [Default Scan Settings](#) on page 41.

Change the Bluetooth Scanner Settings

When the Bluetooth scanner is paired, changes can be made to the Default profile for the scanner.


1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Scanning**.
3. Tap **Bluetooth Scanner** > **Default profile** > **Data Processing Settings**.
4. Modify the settings to meet your application needs.

To learn more about the scanner settings, see [Data Processing Settings](#) on page 41.

Restore Default Scan Settings

You can easily discard all changes you made to the Default profile and restore the default values.

Note: When you choose the Restore all defaults option from a settings screen in a profile, all the settings in that profile return to their default values.

1. Open the **Default profile**.
2. Tap  in the upper right corner of any of the scan settings screens for the profile.
3. Tap **Restore all defaults**.

Default Scan Settings

Use the following sections to understand the scan settings available for scanner profiles. To learn how to create a new profile, see [Add a Scan Setting Profile](#) on page 48.

Data Processing Settings

Use the Data Processing Settings to specify how barcode data is processed by the computer.

Data Processing Settings

| Setting | Description | Default |
|--------------|---|------------|
| Wedge | Enable or Disable the scan wedge feature. | Enabled |
| Wedge Method | Specify wedge method: Standard or Keyboard | Standard |
| Charset | Select the character set to use when interpreting the barcode data into a string. | ISO-8859-1 |

| Setting | Description | Default | | | | | | | | | | |
|---------------------|---|-----------|----------------------------|----|----|----|----|----|---|----|-----|------|
| Prefix | <p>Defines the string added before the decoded barcode data. Substitutions occur within the Prefix string values.</p> <table border="1"> <thead> <tr> <th>Substring</th> <th>Replacement Character Code</th> </tr> </thead> <tbody> <tr> <td>\r</td> <td>13</td> </tr> <tr> <td>\n</td> <td>10</td> </tr> <tr> <td>\t</td> <td>9</td> </tr> <tr> <td>\\</td> <td>'\'</td> </tr> </tbody> </table> | Substring | Replacement Character Code | \r | 13 | \n | 10 | \t | 9 | \\ | '\' | None |
| Substring | Replacement Character Code | | | | | | | | | | | |
| \r | 13 | | | | | | | | | | | |
| \n | 10 | | | | | | | | | | | |
| \t | 9 | | | | | | | | | | | |
| \\ | '\' | | | | | | | | | | | |
| Suffix | <p>Defines the string added after the decoded barcode data. Substitutions occur within the Suffix string values.</p> <table border="1"> <thead> <tr> <th>Substring</th> <th>Replacement Character Code</th> </tr> </thead> <tbody> <tr> <td>\r</td> <td>13</td> </tr> <tr> <td>\n</td> <td>10</td> </tr> <tr> <td>\t</td> <td>9</td> </tr> <tr> <td>\\</td> <td>'\'</td> </tr> </tbody> </table> | Substring | Replacement Character Code | \r | 13 | \n | 10 | \t | 9 | \\ | '\' | None |
| Substring | Replacement Character Code | | | | | | | | | | | |
| \r | 13 | | | | | | | | | | | |
| \n | 10 | | | | | | | | | | | |
| \t | 9 | | | | | | | | | | | |
| \\ | '\' | | | | | | | | | | | |
| Wedge as Keys | List of character values to wedge as keys, represented as a comma-separated list of decimal values. | 9,10,13 | | | | | | | | | | |
| Data Editing Plugin | Specify a data editing plug-in and edit plug-in settings. | None | | | | | | | | | | |
| Symbology Prefix | <p>Specify a symbology identifier prefix to the barcode data. Options include:</p> <ul style="list-style-type: none"> • None • Honeywell • AIM | None | | | | | | | | | | |
| Launch Browser | <p>Enable or disable URL barcode handling. If a barcode starts with http:// or https://, the browser opens using the barcode data as a URL.</p> <p>Corresponds to BarcodeReader property: PROPERTY_DATA_PROCESSOR_LAUNCH-BROWSER</p> | Enabled | | | | | | | | | | |

| Setting | Description | Default |
|------------------|--|----------|
| Scan to Intent | <p>Enable or disable special handling of scan-to-intent barcodes.</p> <p>Applies to barcodes in one of the following formats: '/' ACTION '/' ACTION '\$' extra-data</p> <p>Where: ACTION and extra-data are any string of characters.</p> <p>Launches an application listening for the intent.</p> <p>Intent action: "com.honeywell.scantointent.intent.action." + ACTION</p> <p>Intent extra: "com.honeywell.scantointent.intent.extra.DATA" contains the remainder of the barcode data after the first '\$' character.</p> <p>Corresponds to BarcodeReader property: PROPERTY_DATA_PROCESSOR_SCAN_TO_INTENT</p> | Enabled |
| Launch EZ Config | <p>Enable or disable special handling of EZConfig barcodes.</p> <p>Applies to EZConfig barcodes that are encoded with the Aztec symbology and contain specific header data.</p> <p>Corresponds to BarcodeReader property: PROPERTY_DATA_PROCESSOR_LAUNCH_EZ_CONFIG</p> | Enabled |
| Data Intent | <p>Enables the reception and processing of barcode data without using an SDK or library.</p> | Disabled |

Symbology Settings

Use the Symbology Settings to enable or disable barcode symbologies for the selected scan setting profile.

- Tap the check box next to a symbology name to enable (check mark) or disable (no check mark) decoding for that symbology.
- Tap the symbology name to view and modify additional configuration parameters for the symbology selected.

To view a list of default settings for supported symbologies, see [Barcode Symbologies](#) on page 110.

Decode Settings

Adjust the Decode Settings when scanning barcodes that are densely packed or poor quality.

Decode Settings

| Setting | Description | Default |
|-------------------------|---|----------|
| Center Decode | <p>When enabled, the imager scans and decodes a barcode only if part of the barcode is at the center of the aimer window. This is useful in situations where several barcodes may be very close together in the imager field-of-view.</p> <ul style="list-style-type: none"> Tap the check box to toggle the feature On or Off. Select Center Decode to adjust the Window dimensions. Honeywell recommends leaving the settings at 50 (default) to define the “center” area for the barcode. <p>Configurable parameters:</p> <ul style="list-style-type: none"> Window top Window bottom Window left Window right Aimer Finder Aimer Finder Timeout | Disabled |
| Decode Security | Use this setting to control the reading tolerance of the decoder. Lower settings are more lenient when reading low quality barcodes while higher values are more strict. | 2 |
| Decoder timeout | Set the amount of time in seconds that the scanner will timeout if a readable barcode is not found. | 150 |
| Decode Filter | <p>Use these settings to modify or reject data strings.</p> <ul style="list-style-type: none"> Decode Filter Script The Decode Filter Script is used to configure a filter for decode results during scanning. For example, a filter could be used to reject barcodes that don't begin with certain characters, remove leading characters (like "00") from the beginning of a barcode, or only scan barcodes that begin with certain characters. Decode filter timeout (ms) The decode filter timeout option can be used to disable the logic inside the filter script after a given amount of time. Debug level Set the filter information level. The default level is 0, no information. Higher levels emit more information. Level 4 emits the most information. | none |
| Poor Quality 1D Reading | Enable this setting when scanning damaged or badly printed 1-D barcodes to improve barcode read success. | Disabled |
| Video mode | <p>Use this setting to specify whether normal or inverse decoding for linear symbologies is enabled during the execution of Decode. By default normal video is enabled.</p> <p>Options include:</p> <ul style="list-style-type: none"> Normal Inverse Normal and Inverse | Normal |

| Setting | Description | Default |
|--------------------------------|--|-----------------|
| DPM mode (license required) | <p>Use this setting when scanning Direct Part Marking (DPM) barcodes that are etched or imprinted directly into the surfaces of materials including metal and plastic.</p> <p>Options include:</p> <ul style="list-style-type: none"> • No DPM optimization • Dotpeen DPM decoding • Reflective DPM decoding | No optimization |
| Region of Interest | <p>Set the ROI for decoding. Options include:</p> <ul style="list-style-type: none"> • Disable ROI is disabled and the entire original image is sent to the decoder. • Standard Use the aimer position to weight activity. Activity calculated on the row and the column in the middle of each cell. The ROI window may not include the aimer. • Standard, aimer centered Activity calculated on the row and the column in the middle of each cell. The ROI window will always include the aimer. • DPM, aimer centered Activity calculated on 4 rows and 2 columns in each cell. The ROI window will always include the aimer. • Kiosk/presentation application Ignore aimer position, no weight activity. Activity calculated on the row and the column in the middle of each cell. The ROI window may not include the aimer. • Learning Engine When selected, the computer will receive continuous updates to improve the decoder software based on your specific environment. The Staging Hub Agent must also be enabled. • Smart Detection Measures image gradients and clusters regions with high gradients. ROIs are prioritized based on their gradient magnitudes and densities. | Disabled |
| Image Binning | <p>Enable internal binning of the image to decrease the average decode time. When the setting is enabled, the decoder will bin every 2x2 area in the image.</p> | Disabled |
| Multicode Scan | <p>Use this setting to scan multiple barcodes at one time. You can input the number of barcodes that you want to scan (up to 10) and specify details for each to include:</p> <ul style="list-style-type: none"> • Symbology • Code Length • Start Position • Suffix • Incomplete Transmission Requirement | Disabled |

| Setting | Description | Default |
|------------------------------|---|----------|
| Preferred Symbology Settings | <p>Set the priority level (High or Low) for symbology codes. This is used when you want to specify one symbology as a higher priority over other symbologies in situations where both barcode symbologies appear on the same label, but the lower priority symbology cannot be disabled. If a code is set as a High Priority, the decode of that symbology is accepted immediately. If a code is set as a Low Priority, the decode is buffered to see if a decode of a preferred High Priority symbology can be found within a given timeout period.</p> <p>To apply Preferred Symbology Settings, tap the check box.</p> <p>Preferred Timeout (ms) - The amount of time milliseconds that will allow the scanner to search for a High Priority barcode after a Low Priority barcode has been encountered. The default is 500ms.</p> <p>To set the priority level for a symbology, tap the code in the list then select the priority. The default for all codes is "High Priority."</p> | Disabled |
| Fast Linear Decode | Enable the Fast Linear Decoder to accelerate decoding of well-printed 1D barcodes. | Enabled |
| GS1 Digital Link Conversion | Converts GS1 Digital Link Codes from web URI syntax to traditional GS1 element string syntax. | Disabled |

Imager Settings

You should not need to modify the Imager Settings. The **Override Recommended Values** setting is disabled by default. The recommended Imager Settings are designed to work in a wide range of environments and should only be modified if you have an advanced understanding of imagers.

Trigger Settings

Use the Trigger Settings to configure how the scan buttons work.

Trigger Settings

| Setting | Description | Default |
|---------------------|--|----------|
| Enable Scan Trigger | Enable or Disable activating the imager by pressing the side scan buttons or the virtual Scan button in the Scan Demo app. | Enabled |
| Scan delay | Set the minimum amount of time in seconds before the scanner can read another barcode. | 0 |
| Decode Timeout | Set the number of seconds before the scanner automatically turns Off if the scan button is pressed and nothing has successfully decoded. | 20 |
| Trigger Scan Mode | <p>Set read behavior on scan button press.</p> <p>Options available:</p> <ul style="list-style-type: none"> • One Shot • Continuous • Read on release • Read on second trigger press | One Shot |

| Setting | Description | Default |
|---------------------|--|----------|
| Presentation Mode | <p>Presentation Mode uses ambient light and scanner illumination to detect barcodes. When in Presentation Mode, the LEDs remain dim until a barcode is presented to the scanner, then the aimer turns On and the LEDs turn up to read the code. If the light level in the room is not high enough, Presentation Mode may not work properly.</p> <p>Click on Presentation Mode to access available options:</p> <ul style="list-style-type: none"> • Enable Presentation Mode • Active Phaser Aimer On • Idle Phase Illumination On • Idle Phase Illumination Intensity • Active Phase Illumination Period | Disabled |
| Same symbol timeout | Set the minimum buffer time in seconds before the scanner reads the same barcode. This can be adjusted to prevent inadvertent scans of the same barcode if the code is left in the scan field longer than the Decode Timeout limit. The default same symbol timeout is 1000 seconds. | Disabled |

Notification Settings

Use the Notification Settings to configure how your computer responds when you scan a barcode.



Notification Settings

| Setting | Description | Default |
|---|---|---------------|
| Good Read Notification | Enables or disables a good read notification. The notification consists of a green blink of the Good Read LED, a short beep, and an optional short vibration. | Enabled |
| Good Read Notification File | Use the default notification sound for a good read or specify an audio file to use instead. | Default Sound |
| Bad Read Notification | Enables or disables notification of a failed scan. The notification consists of a red blink of the Good Read LED, an error beep, and an optional short vibration. | Disabled |
| Vibrate On Notification | Enables or disables whether the computer vibrates when there is a good or bad read. | Disabled |
| Vibrate Duration | When Vibrate On Notification is enabled, sets the length of the vibration in microseconds. | 100 |
| Package Verification | Package verification automatically stores the package images from the near sensor to determine the context in which the barcode was read. This data can be used as proof of delivery and can be uploaded to the Honeywell or customer cloud using SSClient or customer-specific software. Select the check box to turn the Package Verification setting On. | Disabled |
| Package Verification Max Folder Size (MB) | The maximum folder size allowed for the folder that stores Package Verification images. Images are stored in honeywell\ImageCapture\PackVerf_Images. | 200 MB |

| Setting | Description | Default |
|------------------------------------|--|----------|
| Pkg Verify High Quality Image Save | Enable this option to add new images and delete old images when the maximum folder size is reached. If this is not enabled, new images will not be stored until files are removed by the user. | Disabled |

Add a Scan Setting Profile

To create a scan setting profile for a custom app on the computer:


1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Scanning** > **Internal Scanner**.
3. Tap  in the upper right corner of the app screen.
4. Take one of the following actions:
 - Tap the profile name field, and then add a new name.

OR

 - Tap the **select an application** option, and then choose an app from the list.

The new profile appears on the Internal Scanner profile list. You can now select and modify the scan settings for the new profile.


Delete a Scan Setting Profile

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Scanning** > **Internal Scanner**.
3. Tap and hold the profile you want to delete, select **Delete**, and then click **OK**.

About the Optional Digital Scan Button

By default, the imager is enabled for scanning with the left and right Scan buttons configured to trigger the imager. If your application environment requires use of an on-screen Scan button, enable the Digital Scan Button feature in the Settings app. Once enabled, you can then modify the appearance of the on-screen Scan button and select the apps the button appears in.

Enable and Configure the Digital Scan Button

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Digital Scan Button**.

3. Tap **Enable Digital Scan Button** to turn the feature On. A preview of the button appears at the bottom of the screen.
4. Configure the button appearance. As you adjust the settings, the preview of the button updates.
 - Tap **Select Button Size** and then choose Small, Medium, or Large.
 - Tap **Select Button Color** and then choose from seven color options. Default color is black. Tap a dot to select the color, and then select **OK** to confirm.
 - Use the slider under **Set Transparency Level** to adjust how transparent the button appears on the application screen.
5. Drag the preview of the Scan button to the location where you want it to appear on the screen. Once you have positioned the button, tap the **Set Button Location** toggle button to lock it into position.
6. Tap **Choose Application**.
7. Check the box next to all the applications where you want the digital scan button to be available.
8. Select **OK**.
9. Tap the **Back** arrow to return to the Settings screen.


The digital scan button appears on the screen when you open any of the apps you selected during the button setup. Tap and hold the button to activate the imager and scan a barcode.

Scan Barcodes

By default, the computer imager is enabled for scanning. It supports omni-directional (360°) barcode scanning and an aiming beam is provided to help assist with targeting barcodes.

Before you start scanning barcodes, go into **Settings > Honeywell Settings > Scanning > Internal Scanner** and modify the scan profile to enable only the barcode symbologies that you need. By reducing the active symbology list, you can increase scan speed.

1. Point the scanner window at the barcode. For optimum performance, avoid reflections by scanning the barcode at a slight angle.
2. Press and hold any **Scan** button.
3. Center the aiming beam over the barcode. Make sure the entire barcode is inside of the illumination frame.



4. Release the **Scan** button when the computer beeps and the Good Read LED briefly turns On. The barcode information is entered into the application in use.

Note: *Not all barcode symbologies are enabled by default. If a barcode does not scan, the correct symbology may not be enabled.*

About Scanning Configuration Barcodes


After completing the out-of-box set up process, Provisioning Mode is automatically turned Off. Scanning a barcode to install applications, certificates, configuration files, and licenses on the computer is restricted unless you enable Provisioning Mode in the Settings app.

To learn more [About Provisioning Mode](#), see page 89.

Use the Scan Demo App

Use the Scan Demo app to read barcodes or to test your symbology decode settings.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap the **Demos** app.
3. Swipe left or right on the screen until **Scan Demo** appears under the turntable. Tap the center of the box image to open the app.
4. Point the scanner window at the barcode.
5. Press and hold either side **Scan** button or tap **Scan** on the computer screen.
6. Center the aiming beam over the barcode. Make sure the entire barcode is inside of the illumination frame.
7. Release the **Scan** button when the computer beeps and the Good Read LED briefly turns On. Barcode information appears on the screen.



Note: *In the Scan Demo app, not all barcode symbologies are enabled by default. If a barcode does not scan, the correct symbology may not be enabled.*

Change the Scan Demo Symbology Settings

1. In the Scan Demo app, tap **⋮** in the upper right corner of the screen.
2. Select **Symbology Settings**.

3. Modify the symbology parameters.
 - Tap the check box next to a symbology name to enable (check mark) or disable (no check mark) decoding for that symbology.
 - Tap the symbology name to view and modify additional configuration parameters for the symbology selected.
4. Tap **Back** to return to the Scan Demo app.

You can use the phone feature to make and receive phone calls as well as transmit data through wireless wide-area networks (WWANs).

Note: *Phone features are only supported on CT40/CT40 XP WWAN models (CT40-L1N/CT40P-L1N).*

About the Phone

Phone features on the computer include a speaker and a microphone. You can also use a Bluetooth headset or hands-free kit.

On CT40/CT40 XP WWAN models, the phone feature is enabled by default and supports all cellular radio access technologies (2G, 3G, etc.) for voice and data connections around the globe. These features are certified by PTCRB, GCF, and all major US carriers.

After you turn On the phone and activate service with your wireless carrier, you can customize the phone features and network settings in the **Network & internet** section of the Settings app.

In addition, all CT40 XP models include a dedicated PTT button on the left side of the unit for use with applications that support PTT functionality.

Note: *Both WWAN radios support Network Information and Time Zone (NITZ) messages to automatically set the system time.*


About the SIM Selection App

Supported SIM type and activation methods vary by model and model configuration. During the SIM activation process and/or after activation, you may need to utilize the SIM selection app to provision the computer to your specific use case. This section provides information about navigating the SIM selection app and the features available. See [Activate the Phone](#) on page 55 for information on how to activate the phone.

Use the SIM selection app to configure the SIMs on the mobile computer. You can select which SIM is being used (SIM1 or SIM2) by assigning a SIM to the active SIM slot.

To access the SIM Selection app, swipe up from the bottom of the Home screen to access all apps then tap **SIM Selection** .

The app home screen shows the current SIM configuration.



About Auto Carrier Config Selection


The carrier is selected automatically based on the carrier-provided nano-SIM card. The **Carrier Config** field is set to "Auto" by default. We do not recommend manually selecting the carrier unless there is an issue with connecting to the WWAN network. To set the carrier manually, select your carrier's name from the **Carrier Config** drop-down list. If there is not an appropriate option, select "ROW" (Rest of World).

If you manually configure the Carrier Config but select a carrier that does not match the one on the installed SIM card, you may experience network issues.


Activate the Phone

You can use a SIM card to activate the phone on your CT40/CT40 XP WWAN model computer (CT40-L1N/CT40P-L1N). You can purchase the micro SIM card from your network provider.


1. Select a network carrier. To learn how, see [Activate the Phone](#) on page 55.
2. Press and hold the **Power** button until the options menu appears.
3. Tap **Power Off**.
4. Remove the battery from the computer (see [page 12](#)).
5. Lift up the edge of the SIM card access door.




6. Press down gently and slide the card holder into the unlocked position. Lift the edge of the card holder up.




7. Insert the card in the holder with the contacts facing out.



8. Close the holder with the card installed. Press down gently on the holder and slide it into the locked position.










9. Close the SIM card access door.



10. Install the battery (see [page 13](#)).

Make a Phone Call

Once the phone is activated, you can make a phone call.




1. Tap  in the favorites tray to open the Phone app.
2. Use one of the methods below to enter the telephone number you want to call.
 - Tap  and use the on-screen dialer.
 - Select a person on your saved contact list .
 - Select a favorite on your speed dial list .
 - Select a number from the recent calls list .
3. Tap call .
4. To end the call, tap .

About Apps with Push-to-Talk Functionality

The CT40 XP series provides a dedicated push-to-talk button for use with common apps that support push-to-talk functionality for voice over IP (VoIP) calls over Wi-Fi or cellular data network connections. Once an app with push-to-talk functionality is installed and opened, the button can be used to initiate a call after selecting a contact from within the app.

Answer the Phone

When you receive a phone call, the Incoming Call screen opens. If the caller telephone number is available, it appears on the screen. Depending on your calling plan, you may also see a Caller ID information. All incoming calls are recorded in the Call log. If you miss a call, you receive a notification.

1. On the Incoming Call screen, tap and hold the white call icon.
2. Three icons appear:
 - To answer the call, drag the icon to .
 - To send the caller directly to voice mail, drag the icon to .
 - To send a text message back to the caller instead of answering, drag the icon to .

Switch Apps During a Phone Call

You can multitask while a phone call is in progress. For example, you can use the Calendar app to check your schedule during a call.

Note: *Depending on your WWAN connection and carrier, apps that need a data connection may be unable to access online data while the phone call is in progress. If simultaneous phone calls and data connections are not possible due to provider limitations, voice calls receive priority. Check with your provider for more information.*



1. During a phone call the screen goes dark. Take the phone away from your ear to wake the screen. Tap the **Home** button.
2. Select another app (e.g., Calendar, Contacts). The phone icon appears in the status bar at the top of the screen while the call is connected.
3. To return to the call screen, swipe down from the top of the screen and select ongoing call notification or select **Hang up** if you want to end the call.

Make an Emergency Phone Call

You can use the phone to make an emergency phone call even if the SIM card is missing from your phone. The phone shows no service but the call still goes through if you dial certain emergency numbers (e.g., 112, 911, 000, 08, 118, 119, and 999).

Configure Phone Settings

You can customize settings for the phone, including the ringtone, voicemail options, keypad tones, Internet call settings, and other options.

1. Open the Phone app .
2. Tap  next to the microphone icon at the top of the screen.
3. Select **Settings**. The Call settings menu appears.
4. Change phone settings as necessary.

Note: *Available settings vary depending on your cellular carrier and phone plan.*

Use this chapter to learn how to take pictures and record videos with the color camera(s).


Note: *Due to model and software version differences, screen images and features included in this chapter may vary from what you see on your device.*

About the Color Camera

The CT40 Series comes equipped with a 13-megapixel color camera on the back of the computer.

For added flexibility, the CT40 XP Series comes equipped with two color cameras, an 8-megapixel camera located on the front, and a 13-megapixel color camera on the back.

Both the CT40 and CT40 XP series include 4K video support with image stabilization and advanced software features for enhanced exposure control when taking pictures and videos.



Use the **Photos** app  to view photos and videos stored on the CT40/CT40 XP. By default, the photos and videos captured with the Camera app are saved on the computer under Internal shared storage\DCIM\Camera.


How to Zoom

The camera zoom is controlled using a pinching motion on the touch screen. Place two fingers on the screen at the same time, and then:

- spread your fingers apart to zoom in (enlarge and object), or
- pinch them together to zoom out.







Take a Photo



1. Tap the **Camera** icon  in the favorites tray on the Home screen.
2. Using the screen as a viewfinder, move the computer until you see the image you want to capture.
3. The camera automatically adjusts the focus but you can tap the screen to modify the focal point. By default, the camera senses the lighting in the environment and turns the flash On, if needed.
4. Tap the Volume button  to take a photo.
 - To view the picture, tap the preview near the bottom of the screen.
 - To return to the Camera app, tap the **Back** navigation button.

Note: On CT40 XP models, select  to switch between the front and rear camera. The front camera does not include a Flash feature. CT40 models do not include a front camera.

Record a Video


This section explains how to record video with the camera in the computer.


1. Tap the **Camera** icon  in the favorites tray.
2. Tap  to start recording video.
 - To zoom in or out, pinch or spread your fingers apart.
 - To toggle sound recording On or Off, tap the microphone icon at the top of the screen.
 - To pause recording, select . To resume recording, tap .
 - To capture a still picture during recording, tap the **Camera** icon .
 - To add light while recording, tap the flash icon. Flash is only available with the rear camera on the back of the computer.
3. When you are done recording, tap .

To access the video settings in the Camera app, select the **More Settings** icon , and then **Advanced Settings** .

Change Camera Settings

You can change the camera settings for best results when taking pictures. The camera settings are adjustable from within the Camera app.

1. Open the **Camera** app .
2. At the top of the screen, select any of the following to adjust the settings.



- **More Settings**
Select to access HDR, ProMode, and Advanced settings.


HDR

Tap to quickly toggle HDR mode On or Off. When enabled, the computer automatically captures multiple photos and combines them into one photo, creating the best quality image possible.

Automatic or ProMode

Select ProMode to manually control settings for ISO exposure, white balance, and focus. Select Automatic to have the camera automatically adjust the settings and focus for you.

Advanced Settings

Select the gear  to access settings that allow you to modify the camera setting defaults and to configure how the camera app functions (i.e., General, Still camera, Video camera, System).

- **Color Filters**
Stylize your pictures by applying a filter. Options include: None, Sepia, Negative, Solarize, Posterize, and Aqua.
- **Camera Selection**
Switch between the front and rear camera. CT40 XP models only.
- **Flash Setting**
Select to adjust the camera flash setting (e.g., automatic, no flash or always flash). This option is only available for the rear camera.

Use the Camera as a Flashlight

To use the rear camera as a flashlight:

1. Open Quick Settings (see page [31](#)).
2. Tap the Flashlight icon to toggle the flashlight On or Off.

Note: *The flashlight feature only works if the Camera app is closed.*

CONFIGURE THE COMPUTER

Use this chapter to learn about the available methods for configuring your mobile computer. You can also use this chapter to learn how to configure network communications and wireless security.



How to Configure the Computer

You can configure many parameters on the computer such as the barcode symbologies it decodes or the network settings. The values you set for these parameters determine how the computer operates.

You configure the computer using the Settings app. Or you can use the Wi-Fi Staging app to set up multiple devices with the same base configuration (see page 89).

Start the Settings App

The Settings app is available from the all apps menu and the notification panel.

- Swipe up from the bottom of the Home screen, and then tap **Settings** .
- OR
- Swipe down twice from the top of the Home screen, and then select .

About the Structure of the Settings App

Use this section to learn about the structure of the Settings app so you can find parameters quickly. A search field appears at the top of the screen when you open the Settings app to help you locate settings quickly.

Note: *The Settings app varies by computer model and OS version. Your computer may not include all the features outlined in this section.*

Network & internet

In the Settings app, select **Network & internet** to access the following settings.

| Setting | Description |
|---------------------|--|
| Internet | <ul style="list-style-type: none"> • Turn Wi-Fi radio On or Off. • Lists available Wi-Fi networks in range and the connection status when the radio is turned On. • Add a network Wi-Fi connection and view saved networks. • Tap Network preferences to turn On Wi-Fi automatically, notify for public networks, install certificates, use Wi-Fi Direct, and access Honeywell Wi-Fi settings (see page 79). |
| Calls & SMS | Turn Wi-Fi calling On or Off. Wi-Fi calling allows the computer to use either a Wi-Fi or mobile network for calls, depending on signal strength. |
| SIMs (WWAN models) | <p>Modify mobile network settings, including enabling data access and roaming over mobile networks, selecting access points and network operators, or selecting only 2G networks (to save battery life).</p> <ul style="list-style-type: none"> • View Data use information. • Turn Mobile data On or Off. • Turn Roaming On or Off. • View app data usage. • Set up a data warning and limit. • Turn 4G Calling On or Off. • Access advanced options, including: <ul style="list-style-type: none"> • Preferred network settings • Turn Wi-Fi calling On or Off • Turn carrier video calling with IMS On or Off (requires 4G Calling turned ON) • Automatic or manual network selection • CDMA roaming settings and subscription settings (i.e, RUIM/SIM, NV) • Access point name and selection • Network selection settings |
| Airplane mode | <p>Turn Airplane mode On or Off.</p> <p>Note: When Airplane mode is turned on, phone and Wi-Fi services are turned off. To use Wi-Fi while in Airplane mode, select Internet then choose a Wi-Fi network.</p> |
| Ethernet | <ul style="list-style-type: none"> • Turn Ethernet connection On and Off. • View last Ethernet connection information. |
| Hotspot & Tethering | <ul style="list-style-type: none"> • Enable or Disable using the computer as a portable Wi-Fi hotspot. • Configure Wi-Fi hotspot. • Enable or disable USB, Bluetooth, or Ethernet for sharing mobile data connections. |
| Data Saver | Turn the Data saver feature On or Off. Specify which apps can use unrestricted data. |
| VPN | Set the password parameters for a virtual private network (VPN) connection. |
| Mobile plan | Provides information on your cell phone plan. |

| Setting | Description |
|-------------|--------------------------|
| Private DNS | Select Private DNS Mode. |

Connected devices

In the Settings app, select **Connected devices** to view current, connected devices and to access the following settings.

| Setting | Description |
|------------------------------|--|
| Pair new device | <ul style="list-style-type: none"> Connect to a Bluetooth Device. Lists Bluetooth enabled devices in range. View and rename the computer. View the computer Bluetooth address. |
| USB | <p>Specify whether USB communication is controlled by your device or the connected device.</p> <ul style="list-style-type: none"> Select the type of communication: <ul style="list-style-type: none"> File Transfer MIDI PTP No data transfer Set up file transfer options when File Transfer or PTP is enabled. <p>Note: This setting only appears when the unit is connected via USB.</p> |
| Saved devices | <p>View previously connected devices.</p> <p>Note: This setting only appears once the computer has been paired with another device.</p> |
| Connection Preferences | |
| Bluetooth | <ul style="list-style-type: none"> Turn the Bluetooth radio On or Off. View and rename the computer. Lists Bluetooth enabled devices in range when the radio is turned On. Connect to a Bluetooth Device. View the computer Bluetooth address. |
| NFC | <p>Turn Near Field Communication (NFC) On or Off. When the NFC radio is enabled, data exchanges are allowed when the computer touches another NFC enabled device.</p> <p>Manage apps that use contactless payments. Ask your Honeywell sales representative for information on contactless payment options.</p> |
| Cast | Set up a Cast connection. Cast (project) audio and screen content to a secondary device such as a television. |
| Printing | Set up a printer connection with the computer. Connection options include cloud print services, Wi-Fi printing via a router, and printing via NFC. |
| Chromebook | Set up connection from the computer to a Chromebook. |
| Nearby Share/ Quick Share | Share files with nearby devices. |

| Setting | Description |
|--------------|------------------------------|
| Android Auto | Use apps on your car screen. |

Apps

In the Settings app, select **Apps** to access the following settings.

| Setting | Description |
|--------------------|--|
| All apps | View a list of installed apps. |
| Default apps | View and manage default app use. |
| Screen time | <ul style="list-style-type: none"> Shows Screen time, Notifications received, Times opened. Allows to set app timer. |
| Unused apps | View and manage apps that are unused for over three months. |
| Special app access | Manage apps with special unrestricted access. |

Notifications

In the Settings app, select **Notifications** to access the following settings.

| Setting | Description |
|---|---|
| Manage | |
| App Settings | Manage notifications from apps. |
| Notification history | View recent and snoozed notifications. |
| Conversation | |
| Conversations | View conversations marked as a priority. |
| Bubbles | Allow conversations to appear as floating icons on top of other apps. |
| Privacy | |
| Device & app notifications | Control which apps and devices can read notifications. |
| Notifications on lock screen | Manage how notifications appear on the lock screen. |
| General | |
| Do Not Disturb | Turn On to prevent notifications from appearing. Manage which notifications can appear when Do Not Disturb is On. |
| Wireless emergency alerts | Manage emergency alert notifications. |
| Hide silent notifications in status bar | Turn On to prevent silent notifications from appearing in the status bar. Silent notifications are notifications that do not use a visual or audible alert. |
| Allow notification snoozing | Turn On to enable the ability to snooze a notification by tapping the alarm clock icon at the bottom of a notification. |
| Notification dot on app icon | Turn On to display a notification dot on an app icon when the app generates a notification. |
| Blink light | Turn On to enable the notification LED to blink for notifications. |

| Setting | Description |
|------------------------|--|
| Enhanced notifications | Turn On to organize notifications and enable notifications to provide suggested actions and replies. |

Battery

In the Settings app, select **Battery** to view battery status, use statistics, and adjust features that conserve battery charge.

Note: Some settings in previous OS versions can be found in Display.

| Setting | Description |
|--------------------|--|
| Battery | View current battery charge or charging status. |
| Battery usage | View battery usage from last full charge. |
| Battery Saver | Turn the Battery Saver feature On or Off manually. Set a schedule based on the battery charge percentage (%) remaining that automatically activates the Battery saver feature. Use the slider to set the battery percentage level. Slider adjusts from 5% to 7% and is only available once a schedule is selected. When charging, set the battery saver feature to turn Off when the battery reaches 90%. Default setting. |
| Battery Manager | Turn the Battery Manager On or Off. Battery manager detects when apps drain the battery. |
| Battery percentage | Set to show or do not show battery percentage in status bar. |

Storage

In the Settings app, select **Storage** to view statistics on available and used storage space on the device and on any portable storage cards installed.

Sound & vibration

In the Settings app, select **Sound & vibration** to modify the audio and sound settings. To learn more, see [Audio Settings](#) on page 21.

Display

In the Settings app, select **Display** to access the following settings.

| Setting | Description |
|---------------------|--|
| Brightness | |
| Brightness level | Set the Brightness level manually if the Adaptive brightness feature is turned Off. |
| Adaptive brightness | Set how the screen in sleep mode responds when new notifications are received (e.g., wake or do not wake). |
| Lock Display | |
| Lock screen | Select what to show on the lock screen and when to display new notifications. |

| Setting | Description |
|------------------------|---|
| Screen timeout | Set the inactivity time limit before the unit automatically turns Off the screen to save battery power (seconds or minutes). |
| Appearance | |
| Dark theme | Enable dark mode to switch app backgrounds to a black color. |
| Display Resolution | Set the resolution of the screen. |
| Display size and text | <ul style="list-style-type: none"> Adjust Font size. Adjust Display size. Turn Bold text On or Off. Turn High contrast text On or Off. Reset settings to default. |
| Color | |
| Night Light | Activate the Night Light feature to adjust the screen tint to a light amber for easier viewing and reading in dim light or for the hours you use the device before going to sleep. Set the feature to stay On or define a schedule to turn the feature On or Off. You can manually adjust the intensity of the amber hue once the feature is activated. |
| Colors | Adjust the screen color settings (e.g., Natural, Boosted, Adaptive). |
| Other display controls | |
| Auto-rotate screen | Set the screen to switch from portrait to landscape when the unit is rotated. When Off the screen does not automatically rotate. |
| Display Resolution | Select from High or Full screen resolution. Note: Full resolution uses more battery power than High. Changing the resolution setting may cause some apps to restart. |
| Screen saver | Set the default screen saver as well as when to display it. Tap Settings to select screen saver style or to turn Night mode On. |
| Tap to wake | When turned On, you can double-tap anywhere on the display to wake the device. |

Wallpaper & style

In the Settings app, select **Wallpaper & style** to manage background images on the Home and lock screens.

Accessibility

In the Settings app, select **Accessibility** to access screen readers, display settings, interaction controls, audio, and on-screen text features to improve accessibility levels.

| Setting | Description |
|-----------------|---|
| Downloaded apps | Manage accessibility apps downloaded to the computer. |
| Screen Reader | |
| Select to Speak | When turned On, you can tap specific items on the screen to hear them read aloud. |

| Setting | Description |
|-----------------------|--|
| TalkBack | When turned On, the feature provides spoken feedback so you can use the computer without always looking at the screen. TalkBack describes your actions and tells you about alerts and notifications. |
| Display | |
| Display size and text | Configure display features that may aid visual accessibility levels. <ul style="list-style-type: none"> • Adjust Font size. • Adjust Display size. • Turn Bold text On or Off. • Turn High contrast text On or Off. • Reset settings to default. |
| Color and motion | Configure color and motion features that may aid visual accessibility levels. <ul style="list-style-type: none"> • Enable and manage Color correction options. • Enable and manage Color inversion options. • Turn Dark theme On or Off. • Turn Large mouse pointer On or Off. |
| Extra dim | Turn On to dim the screen beyond the minimum brightness level. |
| Magnification | Manage options to quickly zoom the screen to make content larger. |
| Interaction controls | |
| Accessibility Menu | Use a large on-screen menu to control the computer. |
| Timing controls | Manage timing options for actions. <ul style="list-style-type: none"> • Adjust the Touch & hold delay. • Time to take action (Accessibility timeout). • Set the Autoclick delay (dwell timing) to automatically click after the pointer stops moving. |
| System controls | Set interaction controls that may aid physical accessibility levels. <ul style="list-style-type: none"> • Set System navigation (Gesture navigation or 3-button navigation). • Turn the Power button ends call feature On or Off. • Turn Auto-rotate screen On or Off. |
| Vibration & haptics | Enable and manage vibration and haptics features. <ul style="list-style-type: none"> • Turn Vibration and haptics On or Off. • Configure vibration for calls. • Turn Notification and Alarm vibration On or Off. • Turn Touch feedback On or Off. • Turn Media vibration On or Off. |
| Captions | |
| Caption preferences | Turn the Show captions feature On or Off and manage options for captions. |
| Audio | |
| Audio Description | Turn On to hear a description of the action during supported movies and shows. |
| Hearing aids | Pair a hearing aid with the computer. |

| Setting | Description |
|-------------------------|--|
| Audio adjustment | Manage audio options. <ul style="list-style-type: none"> • Turn Mono audio On or Off. • Set Audio balance if using headphones or hearing aids. |
| General | |
| Accessibility shortcuts | Manage the accessibility button, which provides a shortcut for accessibility options from any screen. |
| Text-to-speech output | Select and configure the preferred TTS, language, speech rate, and pitch of synthesized voice. |

Security

In the Settings app, select **Security** to view the latest Security scan results, security updates, and phone encryption status. Access additional settings related to device security.

| Setting | Description |
|--------------------------|---|
| Security status | |
| Google Play Protect | Manually initiate a scan of the apps on the device to check for problems. |
| Find My Device | Allows users to locate, ring, or wipe a device remotely. |
| Security update | Displays the last date security was updated on the device. |
| Device security | |
| Screen Lock | Activate and configure a screen lock (None, Swipe, Pattern, PIN, or Password). |
| More security settings | |
| Smart Lock | Define safe conditions or locations where your phone will stay unlocked (e.g., On-body, Trusted places, Trusted devices, Voice Match). |
| Device admin apps | Manage administrator privileges. |
| Encryption & credentials | View encryption status and manage trusted credentials (e.g., view, install, clear, and edit). |
| Trust agents | View and enable/disable trusted agent apps such as Smart Lock by Google on the device. Trusted agents bypass security based on set parameters. |
| App pinning | Turn the screen pinning feature On or Off. When On, you can pin the device screen to a recently used app where it stays until you unpin the app via the security method chosen. |

Privacy

In the Settings app, select **Privacy** to define privacy settings for the device.

| Setting | Description |
|--------------------|--|
| Privacy dashboard | Show which apps have recently used permissions. |
| Permission manager | Define which apps have access to features on the device, such as the camera or microphone. |
| Microphone access | Turn On or Off microphone access to apps. If set to Off, microphone access is available for emergency calls. |

| Setting | Description |
|------------------------------|--|
| Show passwords | Briefly displays the characters in a password as you type before hiding them. |
| Notifications on lock screen | Select whether or not to show all notification content on the lock screen. |
| Show media on lock screen | Turn On to keep media player open on lock screen. |
| Show clipboard access | Show a message when apps access clipboard content you have copied such as text and images. |
| Autofill service from Google | Automatically fill fields using saved data from your Google account. |
| Activity controls | Choose what type of activities are saved in your Google account. A Google account must be associated with the device to use this feature. |
| Ads | Opt in or out of ad personalization features. When this setting is turned On, ads are personalized with the activity and information from your Google Account. |
| Usage & diagnostics | Automatically send diagnostic, device, and app usage data to Google. By default, this setting is turned Off. |

Location

In the Settings app, select **Location** to define which apps have access to the device's location.

| Setting | Description |
|----------------------------|---|
| Use Location | Turn location services (Google and GPS satellite data) On or Off. Set location mode accuracy and view location request history. |
| Recent access | Lists apps that recently requested location information. |
| App location permissions | View and manage app-level location service permissions. |
| Location services | |
| Earthquake alerts | Provides an alert when an earthquake is detected nearby. For supported regions only. |
| Emergency Location Service | Allows the device to automatically send its location to emergency locations. |
| Google Location Accuracy | Improves location accuracy by using Wi-Fi, mobile networks, and sensors to help estimate the device location. |
| Google Location History | Allows the device to report Location History to Google. A Google account must be associated with the device to use this feature. |
| Google Location Sharing | Allows the device to share its location with anyone in the contacts list. |
| Wi-Fi scanning | Turn Wi-Fi scanning On or Off. When enabled, system apps and services are allowed to detect Wi-Fi networks at any time to improve location services. |
| Bluetooth scanning | Turn Bluetooth scanning On or Off. When enabled, system apps and services are allowed to detect Bluetooth devices at any time to improve location services. |

Safety & emergency


In the Settings app, select **Safety & emergency** to manage options for sending and receiving information in an emergency.

| Setting | Description |
|-------------------------------------|--|
| Open Personal Safety | Opens the Personal Safety app to manage options for sending and receiving information in an emergency. |
| Emergency contacts | Enter contact information to aid first responders in an emergency. |
| Emergency SOS | When turned On, you can press the Power button five times to call for help or sound an alarm. |
| Crisis alerts | Receive notifications about natural disasters and public emergencies in your area. |
| Emergency Location Service | Allows the device to automatically send its location to emergency locations. |
| Earthquake alerts | Provides an alert when an earthquake is detected nearby. For supported regions only. |
| Unknown tracker alerts | Provides an alert when the computer detects an unknown Bluetooth tracker device. |
| Silence notifications while driving | Silences calls and messages when the devices detects that it is in a moving vehicle. |
| Wireless emergency alerts | Manage emergency alert notifications. |

Honeywell Settings

In the Settings app, select **Honeywell Settings** to access the following settings.

| Setting | Description |
|-------------|--|
| Battery LED | Configures the battery LED behavior. To learn more, see Change the Battery Status LED Behavior on page 16. |

| Setting | Description |
|-------------------------|---|
| Battery Optimizer | <p>View battery status and app usage information.</p> <p>Tap Optimize Battery to create and enable or disable a battery optimization profile that implements a group of settings to conserve power.</p> <p>Options include:</p> <ul style="list-style-type: none"> • None When selected, no battery optimization profile is active. • Energy Saver This pre-defined profile implements UI settings that optimize battery conservation. • Cold Storage This pre-defined profile implements UI settings that optimize battery savings in cold storage environments. • Custom Profile Tap to create a custom battery profile that balances your application needs with energy saving settings. You can turn location services On or Off, configure sound and vibration options, modify brightness and timeout display options, turn UI transition animations On or Off, and turn background services On or Off. |
| Digital Scan Button | Enable and configure the optional digital scan button. To learn more, see About the Optional Digital Scan Button on page 48. |
| Display Dock | For information about these settings, see the CT4x Series Accessories Universal and Standard User Guide, available at sps.honeywell.com . |
| Honeywell Power Setting | Turn Unattended Mode On or Off. When Unattended Mode is On, healthcare apps will continue to notify clinicians of critical communication, even though the unit appears to be in sleep mode. |
| HXLogger | <p>The HXLogger is an advanced diagnostic log service that provides a basic log service, plug-ins for modified log services, and a log manager.</p> <ul style="list-style-type: none"> • Tap HXLogger to turn the basic log service On or Off. When enabled the service records app and system diagnostic troubleshooting information into four basic log files: main log file, radio log, event log, and kernel dynamic log. • Tap Kernel dynamic log to toggle the feature On or Off and to set the Input file name and Input function name. This log is typically used by advanced software application developers. • Tap Plugin to view and enable additional log services and custom plug-ins. • Tap Manager to change the default log path, delete logs, or upload logs for technical support troubleshooting. <p>Select the more icon  to select the max bootset count or to manually Sync Log.</p> |
| Key WakeUp | Set the buttons you want to use to wake the computer from sleep mode. Options include: Left Scan, Right Scan, Volume Up, Volume Down. By default, the Left and Right Scan buttons are enabled for wake up. |
| Keyremap | Change (remap) a button or key function. To learn more, see Remap a Button on page 30. |
| Provisioning Mode | Enable or disable unrestricted installation of applications, certificates, configuration files, and licenses. Provisioning Mode is turned Off by default. To learn more About Provisioning Mode , see page 89. |

| Setting | Description |
|----------------------|--|
| Scanning | Configure the computer imager. To learn more, see Change the Scanner Settings on page 40. |
| Smart Sensor | Configures the integrated motion detection sensors for advanced power management. Options include: Keep awake on motion, Wake on motion, Face down suspend. |
| Staging Hub Agent | Use the agent and settings to connect the computer to the Honeywell Staging Hub Foundation software platform; a centralized software platform IT integrators and administrators can use as a solution for managing, monitoring, and deploying Honeywell devices in a connected workspace environment. |
| RFID | Manage default settings profiles for Honeywell RFID readers. To learn more, see Configure RFID Settings beginning on page 97. |
| Touch Screen Profile | Optimize screen interactions by selecting a touch screen profile designed specifically for your use case. To learn more, see Select a Touch Screen Profile to Optimize Performance on page 18. |
| Voice Wedge | Voice-to-text conversion tool that can be triggered by a specified start word or key press event. Voice Wedge can be configured to take effect globally or only for an associated application. |
| Waas/Sbas Settings | Toggle On or Off to manage GPS accuracy. |
| Web Applications | Enables access for the Honeywell Mobility SDK for Web apps and port selection. |
| Wi-Fi Staging | Use the Honeywell Wi-Fi Staging app to quickly set up new devices by configuring one device and using it to stage others. Wi-Fi Staging can also be used to enroll devices in a Mobile Device Management (MDM) system by connecting units to a specified network and downloading and installing the specified MDM client app. To learn more, see About Wi-Fi Staging on page 89. |

Passwords & accounts

In the Settings app, select **Passwords & accounts** to access the following settings.

| Setting | Description |
|-----------------------------|--|
| Passwords | Manage saved passwords. |
| Autofill service | Manage password management services. |
| Add account | Select to add and manage a Corporate or Email account on the computer. |
| Automatically sync app data | Turn auto-sync On or Off for accounts. Turning the feature On allows apps to refresh data automatically. |

Digital Wellbeing & parental controls

In the Settings app, select **Digital Wellbeing & parental controls** to access Digital Wellbeing tools and parental controls. For more information, see <https://wellbeing.google/>.

Google

In the Settings app, select **Google** to set up and manage your Google accounts and services.

System

In the Settings app, select **System** to access the following settings.

| Setting | Description |
|----------------------------|---|
| Language & input | <ul style="list-style-type: none">Set the preferred language for the computer and for specific apps.Set and manage Virtual and Physical Keyboard input methods.Set up voice input, on-device recognition, and text-to-speech output.Configure the spell checker and personal dictionary.Adjust the pointer speed. |
| Gestures | <ul style="list-style-type: none">Turn Quickly open camera On or Off.Set the system navigation options for buttons on the screen and swiping.Set the press and hold power button option to open the power menu or the Assistant.Set the Prevent ringing option: Vibrate, Mute, or Do Nothing. |
| Date & time | Configure all date and time settings. To learn more, see Set the Time Zone on page 33. |
| Scheduled power on and off | Set a schedule to power the computer On and Off. |
| Backup | Turn the Google Drive backup feature On or Off. When enabled, phone data (e.g., apps, apps data, call history, contacts, device settings, SMS, Wi-Fi passwords, and permissions) is automatically backed up to the Google Drive. |
| Multiple users | <ul style="list-style-type: none">Modify the owner profile name and add profiles for other people who use the computer.Activate a different user profile.Add a guest user or delete guest activity.Enable or disable allowing users to be added from the lock screen. |
| Developer options | Enable developer-specific options such as USB debugging and SD card protection. This option only appears under System settings if you enable the feature. To learn more, see Unlock Developer Options on page 37. |
| Reset options | Select from the following reset options: <ul style="list-style-type: none">Reset Wi-Fi, mobile & Bluetooth. Use to reset all network settings, including Wi-Fi, mobile data, and Bluetooth.Reset app preferences. Use to reset app preference back to defaults. This includes apps you disabled, notification changes, default app actions set, background data restrictions for apps, and permission restrictions.Enterprise data reset. To learn more, see About an Enterprise Data Reset on page 106.Erase all data (factory reset). To learn more, see About a Full Factory Reset on page 107. |

About phone

In the Settings app, select **About phone** to access the following information.

| Setting | Description |
|---|--|
| Basic info | |
| Device name | A nickname to identify the device. To change, tap Device name and enter a new name. |
| Phone number* | The phone number(s) assigned to the device. |
| Legal & regulatory | |
| Legal information | Provides links to third-party licenses and other legal information. |
| Compliance information | Displays certification and compliance information. |
| Compliance Logo | Displays regional compliance marks. |
| Device details | |
| SIM status* | Displays information on the SIM card in the device that can be used for diagnostic purposes. |
| Model | Displays the model number, serial number, and hardware version of the device. |
| IMEI* | Displays the International Mobile Equipment Identify number. |
| Android version | The version of Android on the device. Tap to view additional details. |
| Device identifiers | |
| Asset number | Asset tag assigned to the device. |
| IP address | IP address associated with the device. |
| Wi-Fi MAC address | View information about saved Wi-Fi networks. |
| Device Wi-Fi MAC address | Wi-Fi MAC address associated with the device. |
| Bluetooth address | Bluetooth address associated with the device. |
| Second BLE MAC address | Bluetooth Low Energy address associated with the device. |
| Up time | Time the device has been running since powering on or restarting. |
| Software component version | Select to view the software component version list. |
| Build number | Kernel number installed. |
| * If your WWAN model uses a dual SIM card setup, both SIM Slot 1 and SIM Slot 2 will be listed. | |

About Network Communications

You can easily add the mobile computer to your wireless or wired data collection network. Connect the CT40/CT40 XP to your computer using:


- 802.11 a/b/g/n/ac radio communications.
- Ethernet communications.

- Bluetooth communications.
- USB communications.

Connect to a Wi-Fi Network

The computer contains an 802.11 a/b/g/n/ac radio to transfer data using wireless communications. Before you connect to a Wi-Fi network, you need to know about your network security protocol and its required credentials.


By default, the 802.11 radio is disabled.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **Internet**.
3. Tap **Wi-Fi** to toggle the radio On or Off.
4. On the list, tap a network name to initiate a connection.

To add a network if it does not appear on the list:

- a. Navigate to the end of the discovered network list, and then tap **Add network**.
 - b. Type the Wi-Fi network name (SSID).
 - c. Choose a security protocol and add any required information.
 - d. Tap **Save**.
5. Enter any required information if the network is secured (e.g., password, key, or certificate name).
 6. Tap **Connect**.



Once you connect to a saved Wi-Fi network:

- Tap the network name on the list to view details (e.g., status, signal strength, speed, frequency, security type).
- To edit connection details, tap the network name on the list to view details and then tap the Edit icon .
- The computer automatically connects to the same network when the network is in range and the Wi-Fi radio is turned On.
- To view a list of only your saved networks, tap **Saved networks**.
- To remove a network from your saved list, tap the network name and select **Forget**. You can do this for networks you no longer use.

Configure Proxy Settings for a Wi-Fi Network


If you need to connect to network resources through a proxy server, you can configure settings for the proxy server for each Wi-Fi network you add. By default, the Wi-Fi networks you add are not configured to connect through a proxy server.

Note: Proxy settings apply only to the Wi-Fi network you modify. You must change proxy settings for each network requiring a proxy server.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **Internet**. The list of available Wi-Fi networks appears.
3. Select the network to display the Network details.
4. Tap the Edit icon .
5. Tap **Advanced options**.
6. Under Proxy, select **Manual**.
7. Enter the proxy settings for the network.
8. Tap **Save**.



Disable Wi-Fi Notifications and Set WLAN Radio Sleep Parameter

By default, when Wi-Fi is enabled, you receive notifications in the Status bar when the computer discovers a wireless network. You can disable these notifications.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **Internet**. Verify the Wi-Fi radio is turned On.
3. Tap **Network preferences**.
4. Tap **Notify for public networks** to toggle the setting On or Off.


Fix Connectivity

If you have connectivity issues, you can try to resolve the issue by resetting the Internet connection. The Fix Connectivity function restarts the Wi-Fi subsystem and radio modem. Saved Wi-Fi networks are not erased by this action.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **Internet**.
3. Tap . The Wi-Fi subsystem restarts and the radio modem resets.


Honeywell Wi-Fi Settings

To access Wi-Fi preference settings for advanced configuration of the wireless 802.11 radio in the mobile computer:

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **Internet**.
3. Tap **Network preferences**.
4. Tap **Honeywell Wi-Fi Settings**.
5. Tap a setting to enable or disable the option or to access additional parameters that configure the Wi-Fi radio.

Connect to an Ethernet Network

To connect the computer to an Ethernet network, you need a CT40 Ethernet Home Base or CT40 Net Base.

1. Make sure the base is connected to your Ethernet network.
2. Place the computer in the base.
3. Swipe up from the bottom of the Home screen to access all apps.
4. Tap **Settings**  > **Network & internet** > **Ethernet**. The Ethernet setting is turned **On** by default.
5. Tap **Ethernet**.

The Ethernet connection screen shows the current Ethernet connection. By default, the computer assumes a DHCP connection and that your network has assigned an IP address automatically. If DHCP is working, the Ethernet base should indicate that communication with the network is occurring.

6. (Optional) To assign a static IP address.
 - a. Tap **DHCP** and then select **Static** from the list.
 - b. Enter the required network information and then tap **Apply**.
7. Tap **Save**.


How to Connect to Virtual Private Networks

The computer supports connecting to virtual private networks (VPNs). This section describes how to add and connect to VPNs. To configure VPN access, you must obtain details from your network administrator. You can view and change VPN settings in the Settings app.

Note: Before you can add or connect to a VPN network, you must enable a screen lock method.


Add a VPN


Before you can connect to a VPN, you must create a VPN profile.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **VPN**.
3. Tap **+** to add a new VPN profile.
4. Enter the required information for the VPN connection. If needed, swipe up on the screen to access all the required information fields.
5. Tap **Save**. The VPN name appears in the VPN list.

Connect to a VPN



Once a VPN profile is created, you can connect to the VPN at any time.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **VPN**.
3. Tap the name of the VPN in the list.
4. Enter any necessary credentials when prompted.
5. Tap **Connect**.

A  appears in the status bar and a notification is received. To disconnect from the VPN, tap the notification.

Edit VPN Information

You can edit an existing VPN profile from the VPN screen.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Network & internet** > **VPN**.
3. Tap and hold the name of the VPN in the list.
4. Tap  to the right of the VPN profile you want to edit.
5. Edit the VPN settings as necessary.
6. When you are done, tap **Save**.

About Wireless Security

The computer provides these security solutions for your wireless network:

- Wi-Fi Protected Access 2 (WPA2™)

- Wi-Fi Protected Access (WPA)
- 802.1x

Honeywell recommends WPA2 security with PSK (Personal) or 802.1x (Enterprise) key management.

Before you set security, you need to enable the radio, set the date, and set the SSID on your computer. To use 802.1x security, you need to load a root certificate on your computer. To use transport layer security (TLS) with 802.1x security, you also need to load a user certificate.

Use the Settings app to access and configure all wireless security settings.

About Certificates

You can use digital certificates to identify the computer for network access or authentication to servers. To use a certificate to identify your device, you must install it in the trusted credential storage on the computer.



Android supports DER-encoded X.509 certificates saved in files with a .crt or .cer file extension. To install a valid certificate with a .der or other extension, you must change the extension to .crt or .cer to install it.

Android also supports X.509 certificates saved in PKCS#12 key store files with a .p12 or .pfx extension. To install a valid key store file with another extension, you must change the extension to .p12 or .pfx to install it. When you install a certificate from a PKCS#12 key store, Android also installs any accompanying private key or certificate authority certificates.

Load a Certificate

To use a certificate, you must install it in the trusted credential storage on the computer.


Note: Apps such as email and browsers that support certificates allow you to install certificates directly from within the app. For more information, see the help that comes with the app.

1. Copy the certificate or key store from your PC to the mobile computer.
2. Swipe up from the bottom of the Home screen to access all apps.
3. Tap **Settings**  > **Security** > **More security settings** > **Encryption & credentials**.
4. Tap **Install a certificate**.
5. Select **CA certificate, VPN and app user certificate, or Wi-Fi certificate**.
6. Tap the Menu icon , and then navigate to the location where you saved the certificate.

7. Tap the certificate or key store to install it. If prompted, enter the key store password and tap **OK**.
8. Enter a name for the certificate and tap **OK**.

Disable or Remove Certificates

If a user or system certificate is compromised, or your organization chooses not to trust it, you can disable or remove the certificate.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Security** > **More security settings** > **Encryption & credentials**.
3. Tap **Trusted credentials**.

The trusted credentials screen has two tabs:

- **System** shows Certificate Authorities (CA) certificates permanently installed on the computer. They can only be disabled.
 - **User** shows CA certificates you have installed yourself. You can remove these certificates.
4. Tap the name of the certificate you want to disable or remove. The Security certificate screen appears.
 5. Scroll to the bottom of the screen and tap **Disable** (for System certificates) or **Remove** (for User certificates).
 6. Tap **OK**.


Note: You can enable a disabled System certificate but if you remove a User certificate, you must install it again to enable it.

About Bluetooth Communications



Your mobile computer is equipped to communicate with other devices using Bluetooth technology. The Bluetooth radio must be turned On to discover, pair, and connect to other Bluetooth devices. System bar icons indicate Bluetooth radio status.

Connect a Bluetooth Device

To connect to a Bluetooth device, you must turn On the Bluetooth radio and then select the device from a list of discovered devices.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Connected devices**.


3. Tap **+ Pair new device**. A list of Bluetooth devices appears.
4. Select a device on the list to initiate a pairing request.
5. When the pairing request message appears:
 - Verify the pairing PIN is the same on both devices, and then tap **PAIR**.OR
 - If the pairing request requires a PIN, enter the **PIN**, and then tap **PAIR**.
6. When the device is successfully paired with the computer, the device name appears under **Saved devices**.
7. (Optional) Once paired to a device, you can connect manually to the device. Tap the device under **Saved devices**. The word “Connected” appears under the paired device name.

The status icon changes from  to .

Note: To disconnect a paired device, tap  next to the name of the paired device and then tap **FORGET**.



Rename the Computer

You can change the name of the computer to make it easier to identify when pairing with other Bluetooth enabled devices and view statistics about received files.


1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Connected devices** > **Connection preferences** > **Bluetooth**.
3. Tap **Device Name** to change the device name. Type the new name and then tap **Rename**.

Rename or Unpair a Paired Device

You can rename a paired device to make it easier to identify on the list or unpair the device to remove it from the paired list.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Connected devices** > **Saved devices**.
3. Tap  next to the paired device.


4. Take one of the following actions:

- To rename the device, tap the Edit icon . Type the new name, and then tap **RENAME**.
- To allow **Internet access** or **Contact and call history sharing**, tap the check box next to the settings and then tap **OK**.
- To unpair the device, tap **FORGET**.

About the Scanner Edge App



Your mobile computer is equipped to communicate with scanners using Bluetooth technology through the Scanner Edge app. The Bluetooth radio must be turned On. System bar icons indicate Bluetooth radio status.

To turn On the Bluetooth radio:


1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Connected devices** > **Connection preferences** > **Bluetooth**.
3. Tap **Use Bluetooth** to toggle the Bluetooth radio On or Off.

Connect a Bluetooth Scanner

To connect to a Bluetooth scanner, the Bluetooth radio must be turned On and then you must scan a pairing barcode with the Bluetooth scanner.



1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Scanner Edge** .
3. Tap the menu icon  and then tap **Pair BT Scanner**.
4. Scan the **Connect Barcode** displayed on screen.

5. When the scanner is successfully paired with the computer, the scanner name appears under Connected Device.



Unpair a Paired Scanner

You can unpair the scanner to remove it from the Connected Device list.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Scanner Edge** .
3. Tap the menu icon  and then tap **Disconnect BT Scanner**.
4. Scan the **Disconnect Barcode** displayed on screen.

About Ethernet and USB Communications

You can use these optional CT40/CT40 XP series accessories to transmit data to and receive data from another device using an Ethernet or USB cable connection:

- Home Bases
- Ethernet Home Bases
- Display Docks
- Snap-on Cup (USB)

Accessory documentation is available for download from the CT40 or CT40 XP product pages at sps.honeywell.com.

For a complete list of compatible accessories for your mobile computer and their part numbers see the *CT40/CT40 XP Accessory Guide* available for download at sps.honeywell.com.

Contact your local sales representative for ordering information.

USB Troubleshooting

- If you have a problem with your workstation computer recognizing the USB device, try downloading and installing the Honeywell-aidc-usb-driver. The driver is part of the Honeywell_Mobility SDK_Android software.zip file. To learn where to get the software, see [Developer Information](#) on page 88.
- Check to make sure you have enabled the USB for file transfer. To learn more, see [Configure USB Connection and Transfer Files](#) on page 24.


Bluetooth, USB, or Ethernet Tethering for Data Connection Sharing

You can share your mobile computer data connection with another device through a USB tethering or Bluetooth tethering connection.

Minimum requirements for USB Tethering

- Mobile computer minimum operating system version of Android 9 or later.
- A compatible USB communication accessory and/or cable.
- A compatible USB-to-Ethernet adapter.

Set up and Connection


1. Connect the devices using a USB accessories and/or cable.
2. On the CT40/CT40 XP, change the USB Preference setting from **USB Charging** to **USB tethering**. To learn more, see [Configure USB Connection and Transfer Files](#) on page 24.
3. Tap **Settings**  > **Network & internet** > **Hotspot & tethering**.
4. Select the type of tether to initiate:
 - **Wi-Fi hotspot**
 - **USB tethering**
 - **Bluetooth tethering**
 - **Ethernet tethering**

Note: To stop sharing the connection, tap **USB tethering** again to turn Off the feature or disconnect the USB accessory.

Minimum requirements for Bluetooth Tethering

- All devices must support Bluetooth communication.

Set up and Connection

1. Pair the CT40/CT40 XP with another Bluetooth enabled device.
2. Verify the other device is set to use a network connection using Bluetooth technology.
3. Swipe up from the bottom of the Home screen to access all apps.
4. Tap **Settings**  > **Network & internet** > **Hotspot & tethering**.
5. Select **Bluetooth tethering** to initiate the shared data connection.

Note: To stop sharing the connection, tap **Bluetooth tethering** again to turn Off the feature.

About Near Field Communication (NFC)


NFC technology provides the ability for short-range, wireless data transfer between the CT40/CT40 XP and NFC tags or other NFC enabled devices placed in close proximity to the back of the computer. All CT40/CT40 XP mobile computers support the following modes of operation:

- **NFC tag reader/writer mode:** The computer reads and/or writes digital information from or to an NFC tag.
- **Peer-to-Peer (P2P) mode:** The computer uses Android Beam and/or Bluetooth technology to transfer screen content (e.g., a picture, contact information, Web page URL, or file) between NFC enabled devices.
- **NFC card emulation mode:** The computer emulates an NFC card (smart card) that an external card reader can access. You can download and install apps for card emulation mode from the Google Play™ store. Some examples include digital wallets (e-wallets) offered by your bank or credit card company and Google Pay™. The app you install determines the type of emulation mode used: Card Emulation with a Secure Element or Host-based Card Emulation. Secure element use is common for financial transactions that require a high level of security in order to provide a secure memory and execution environment for running custom smart card applets and storing your personal information (e.g., account information and credentials).

Note: When using a Universal Integrated Circuit (UICC) card for NFC Secure Element NFC link encryption, install the card in SIM slot 1.

Read an NFC Tag

To read an NFC tag, place the tag near the NFC antenna, close to the battery.



Note: NFC is On by default. To turn NFC On or Off, go to **Settings**  > **Connected devices** > **Connection preferences** > **NFC**.

Developer Information

To download the Honeywell Mobility SDK for Android and EZConfig for Mobility:

1. Go to the *Technical Support Downloads Portal* at honeywell.com/PSSsoftware-downloads.
2. Create an account if you have not already created one. You must login to download the software.
3. Install the *Honeywell Download Manager* tool on your workstation (e.g., laptop or desktop computer) prior to trying to download any files.
4. Navigate to the software:
 - *Honeywell Mobility SDK for Android*
Click on **Software** > **Software and Tools** > **Developer Library** > **SDKs for Android**.
 - *EZConfig for Mobility*
Click on **Software** > **Software and Tools** > **EZConfig for Mobility**.
5. Select **Download** next to the software zip file.

About Provisioning Mode


Once you complete the out-of-box initial setup process, Provisioning Mode is automatically turned Off to improve device security against unwanted modifications to the system.

When Provisioning Mode is turned Off (disabled):

- Configuration barcodes do not scan and process.
- \honeywell\autoinstall folders are inaccessible.

Note: To learn more about network and security for Honeywell mobile computers with Android operating systems, go to sps.honeywell.com.

Enable or Disable Provisioning Mode

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Provisioning Mode**.
3. Tap the button to toggle the provisioning **On** or **Off**.

About Wi-Fi Staging

You can use the Honeywell Wi-Fi Staging app to quickly set up new devices by configuring one device and using it to stage others. Wi-Fi Staging can also be used to enroll devices in a Mobile Device Management (MDM) system by connecting units to a defined network and downloading and installing the MDM client app.

Once you have set up a configuration in the Wi-Fi Staging app on the server device, Wi-Fi staging uses that device as a hotspot and waits for a client to connection. The configuration is distributed to the client device once communication is established between the client and the server device.

Staging Devices

Wi-Fi Staging requires two steps:

1. Set up a master device to act as a server (see next section).
2. Set up the client device (see [Set Up Client Devices](#) on page 92).

Set Up a Device as a Server

Wi-Fi Staging provides two kinds of configurations for a master device acting as a server through a hotspot. Setup of the server device differs based on the staging configuration chosen:

- **Basic Configs** include the most common system settings:
 - System language
 - Bluetooth and NFC
 - System volume
 - Location
 - Network
 - File download
 - Application installation or launch
- **Advanced Configs** allow you to stage your devices with .xml files.

The hotspot on the server device will be named HONEYWELL_WIFI_STAGING.

Note: *We recommend setting up the server before setting up clients. If the server is not created in advance, client setup requires more time and power to scan and search for the hotspot signal.*

Note: *To control bandwidth usage, the server side of Wi-Fi Staging has a maximum limitation of 10 concurrent client connections. If more than 10 client devices attempt to connect to the server device at the same time, staging of some of those clients will be delayed until client connections become available as the staging process progresses.*

Basic Configuration

Basic configuration includes the most common system settings.

1. Tap **Settings** > **Honeywell Settings** > **Wi-Fi Staging** to launch the Wi-Fi Staging app on the server device.
2. Tap **Basic Configs** to start the configuration wizard.
3. Select system language. Tap **+** to add a language. At least one language must be selected. Tap **NEXT**.
4. Select connection preferences. Enable Bluetooth and/or NFC. They are disabled by default. Tap **NEXT**.
5. Select sound preferences. Adjust the default volume for each type of audio by dragging the slider, and then tap **NEXT**.
6. Enable the location switch. It is disabled by default. Tap **NEXT**.
7. Set up **Network & Internet** connection or tap **SKIP** to proceed to Step 9 if you do not want to set up a network connection.

You would need to set up a Network & Internet connection if you want to register devices to an MDM system or the devices being registered need to use applications that require network access.

If you want to set up devices to connect to a Wi-Fi access point, enter the network information:

- a. Tap **Wi-Fi Security** and select either **OPEN** or **WPA/WPA2**.
 - b. Enter the Wi-Fi SSID, and then tap **OK**. This field cannot be left empty.
 - c. Enter the Wi-Fi password. The password must be between 8 and 63 characters long. If you select WPA/WPA2, a password is required.
 - d. Tap **NEXT**.
8. The **Files & Apks** option only appears if you chose to set up Network & Internet connections in step 7.

Enter the locations (URLs) of the **Files & Apks** that you want downloaded.

- The URL should end with the file that you want to download. Wi-Fi Staging names the downloaded file with the file name in the URL.
 - (Optional) You can include a file's hash in the file name. Wi-Fi Staging supports hash algorithms SH1 and SHA256.
 - For security, Only Local Area Network URLs are supported for security. Wi-Fi Staging ignores URLs from Wide Area Networks.
 - Supported network protocols include HTTP or HTTPS.
 - APK files are installed silently and automatically after download.
9. **Final Setting:** Select whether you want to reboot the device after staging is complete. You can also specify an action (intent) to launch Android activities. Tap **NEXT**.
10. Review the items you have configured. If you need to change a setting, tap the Back button to return to the relevant screen.

Tap **Confirmed, start staging now!** to begin. Wi-Fi Staging starts a hotspot on the server device and wait for clients to connect.

11. Proceed to [Set Up Client Devices](#) on page 92.

Configurations are distributed to any client that connects to the server device. Once the data transmission finishes successfully, the name and serial number of the configured client is displayed in the Wi-Fi Staging app on the server device, and the client device skips the Android setup wizard.

Note: *If you included a file's hash in Step 8, Wi-Fi Staging will validate that the hash of the file downloaded to a device matches what you specified. If the downloaded file's hash does not match, the file will be removed from the device.*

Advanced Configuration

Advanced configuration allows you to stage your devices with one or more .xml files created by EZConfig or Enterprise Provisioner. For more information about generating .xml files, see the *Power Tools User Guide* or *Enterprise Provisioner User Guide*.

Note: Advanced Configuration supports .xml files only. Other file types are ignored.

Note: Do not change the default names of .xml files. For example, DeviceConfig.xml is acceptable, but DeviceConfig1.xml is not.

1. Choose one device to act as the server.
2. Tap **Settings** > **Honeywell Settings** > **Wi-Fi Staging** to launch Wi-Fi Staging on the server.
3. Tap **Advanced Configs**.
4. Tap **File directory**.
5. Specify where on the server device the .xml files to be downloaded are located.
6. Tap **NEXT**.
7. Choose the files to be applied. Tap **NEXT**.
8. Review the files you have selected. If you need to change any files, tap the Back button.

Otherwise, tap **Confirmed, start staging now!** to begin. Wi-Fi Staging starts a hotspot on the server device and waits for clients to connect.

9. Proceed to [Set Up Client Devices](#) on page 92.

Set Up Client Devices

The Wi-Fi Staging client runs automatically on the initial boot of a new device. However, it must be started manually on existing devices.

New Devices

This section applies to new, out-of-the box devices only. For existing devices, see [New Devices](#).

1. Set up a server device (see page 89).
2. Place the new devices to be configured within 1 meter (3 feet) of the server device and turn them On. When a new device boots up and begins the setup wizard, it attempts to retrieve configuration from the server device, and a staging progress screen appears.

Note: Client devices should be kept on the Android Welcome or setup wizard screen during staging. If you finish the setup wizard manually, the client side of Wi-Fi Staging stops running.

Configurations are distributed to any client that connects to the server device. Once data transmission finishes successfully, the name and serial number of the configured client appears in the Wi-Fi Staging app on the server device, and the client device skips the Android setup wizard.

Existing Devices

To start the Wi-Fi Staging client on an existing device:

1. Set up a server device (see page 89).
2. Tap **Settings** > **Honeywell Settings** > **Wi-Fi Staging** to turn On the client device and launch the Wi-Fi Staging app.
3. Tap **To be staged**.
4. A message appears notifying you that the Wi-Fi settings on the client device will be reset as part of the staging process. Tap **OK** to confirm you wish to proceed. Staging begins and a progress screen appears.
5. Place the device within 1 meter (3 feet) of the server device and it begins searching the server hotspot for a configuration.

The client device(s) attempt to retrieve the configuration from the server device and displays the staging progress screen. Once the client device receives and applies the configuration successfully, the progress screen is dismissed.

Note: *To stop the staging process on an existing device, tap the Back button on the client device.*

Log Files

Wi-Fi Staging saves a key process and exception log on the device in the following directory: /sdcard/honeywell/Android/data/com.honeywell.wifistaging/Log/.

This directory can be accessed via a file browser on a workstation (e.g., laptop, desk top computer) through a USB file transfer connection with the mobile computer, if Provisioning Mode is enabled.

About Voice Wedge

Voice Wedge is a voice-to-text conversion tool that can be triggered by a specified start word or key press event. When Voice Wedge is activated, the mobile device can capture a user's speech and output it as text in a field in the selected app. Voice Wedge can be configured to apply globally across all apps or only for an associated application.

Note: *Because Voice Wedge is powered by Google speech recognition services, it is only available on Google Mobile Services (GMS) devices.*

Define Trigger Mode

You can define either a spoken word or a key press as the trigger to launch Voice Wedge.

1. Select **Settings > Honeywell Settings > Voice Wedge**.
2. Tap **Trigger Mode**.
3. Tap **Start Word** to define a voice command as the trigger or **Key** to use a key press.
4. If you selected Start Word, tap **Trigger start word** then use the keypad to enter the word. The default trigger start word is “honeywell”.
5. If you selected Key, tap **Trigger key** then select the key to be mapped. You can either press a button (for example, a scan button) or use a virtual key. Note that when a button or key is selected for Voice Wedge, its original use is no longer active.

Associate Applications

By default, Voice Wedge is associated with all applications. You have the option to associate Voice Wedge with a single app.

1. Select **Settings > Honeywell Settings > Voice Wedge**.
2. Tap **Effective Coverage**.
3. Tap **Single app**.
4. Tap **App package name**.
5. Use the keyboard to enter the associated package name, for example, “com.android.chrome”, then click **OK**.
6. To limit Voice Wedge to a specific activity within an app, tap **App activity name** and use the keyboard to enter the activity name. For example, “com.google.android.apps.chrome.Main”.

Define Key Commands

Voice Wedge allows you to define some words so that they will be interpreted as commands rather than being displayed as text when you are speaking. When you say one of these words, Voice Wedge will send a key press.

Under **Key command**, select the check box for words that should be used as keys.

- Enter - When you say, “enter,” an Enter key will be sent.
- Tab - When you say, “table,” a Tab key will be sent.
- Space - When you say, “space,” a space key will be sent.

Select Data Type

By default, Voice Wedge enters both alphabetic and numeric characters. You can also choose to input only alpha or numeric characters.

1. Select **Settings > Honeywell Settings > Voice Wedge**.
2. Tap **Data type**.
3. Tap the data type to input.

Examples:

| Data Type | You say... | Voice Wedge inputs... |
|------------------|-------------------|------------------------------|
| Any | abc123 | abc123 |
| Alpha | abc123 | abc |
| Numeric | abc123 | 123 |

To Use Voice Wedge in an App

Follow these steps to use Voice Wedge in an application on your device. Note that if a specific application is defined in the App Package Name setting, Voice Wedge will only work if you are using that app.

1. Select an app on your device.
2. Tap a data entry field in the app.
3. Say the defined Trigger start word or press the Trigger key. A message indicates, "Waiting for voice input..."
4. Speak normally into the device. The text will populate the selected field.


About RFID Readers

Honeywell mobile computers can be paired with an RFID Reader to provide a high-performance mobile RFID solution. To read RFID tags, you can use applications that are coded to use the RFID reader or applications that receive data through the RFID wedge feature.

Use this chapter to understand how to configure settings that define how the mobile computer interacts with the Honeywell RFID Reader.

Change the RFID Settings

Changes you make to the Default profile apply to all applications with no profile assigned.

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **RFID**.
3. Tap an RFID reader model (IP30, IH25, IH40, IH45).

Note: Refer to the accessories catalog for your mobile device to determine compatible RFID Reader models.


4. Tap **Default profile**.
5. Select from the following:
 - **RFID Reader Settings**
 - **Filter Settings**
 - **Trigger Settings** (model dependent)
 - **Notification Settings**
 - **Data Processor Settings**
6. Modify the settings to meet your application needs.

To learn more about the RFID settings, see [Default RFID Settings](#) on page 98.

Restore Default Scan Settings

You can easily discard all changes made to the Default profile and restore the default values.

Note: When you choose the *Restore all defaults* option from a settings screen in a profile, all the settings in that profile return to their default values.

1. Open the **Default profile**.
2. Tap  in the upper right corner of any of the scan settings screens for the profile.
3. Tap **Restore all defaults**.

Default RFID Settings

Use the following sections to understand the settings available for RFID profiles. To learn how to create a new profile, see page [102](#).

RFID Reader Settings

You should not need to modify the RFID Reader Settings. The **Override recommended values** setting is disabled by default. The recommended RFID Reader Settings are designed to work in a wide range of environments.

RFID Reader Settings

| Setting | Description | Default |
|-----------------------------|--|-------------------|
| Read Mode* | Select the RFID Read mode. | Event mode |
| User defined read mode* | Enter a custom read mode. | None |
| Tag Type* | Defines the types of RFID tags used in an application. | EPC Class 1 Gen 2 |
| Override recommended values | Allow custom RFID reader settings to be created. | Disabled |
| Dense Reader Mode* | Allows the reader to hop between channels within a certain frequency spectrum to prevent other readers in the area from interfering with one another. | Disabled |
| Field Separator* | Sets the character to be used for separating fields in tag data. Choose from space (), comma (,), colon (:), semicolon (;), tab, caret (^), or tilde (~). | Space |
| ID Report* | Enables or disables tag ID reporting after a Read, Write, or Lock command is executed. | Disabled |

*IP30 RFID Reader Settings only.

| Setting | Description | Default |
|----------------------------|---|-----------------|
| No Tag Report* | Enables or disables a NOTAG message, which is sent when no tags are found during execution of a Read, Write, or Lock command. | Disabled |
| Report Timeout (ms)* | Sets the timeout (in ms) for delays in tag reporting in continuous read mode. Range is 0 to 65534. | 0 |
| Initial Q* | Sets the initial Q parameter value used by the Query command. Valid range is 0 to 15. | 4 |
| Field Strength (dB) | Sets the RF power level (in dBm) for the antenna port. | Model dependent |
| Session | Sets the command session parameter to a corresponding EPCglobal Class 1 Gen 2 air protocol command. | Model dependent |
| Bluetooth Power Off (sec)* | Sets the time period (in seconds) for which the Bluetooth radio will search for a Bluetooth connection. Range is 30 to 3600. | 300 |
| Timeout or Tries* | | |
| Timeout Mode* | Enables a timeout mode. Instead of specifying the number of antenna or ID tries, specify an antenna or ID timeout value. If the reader does not find any tags after an antenna or ID try, the reader waits this long before starting the next antenna or ID try. If you enable timeout mode, you need to set the ID Timeout and Antenna Timeout values. | Disabled |
| ID Timeout (ms)* | Sets the maximum time period (ms) during which attempts are made to find tags before a response is returned to a READ or WRITE command. Range is 0 to 65534. | 100 |
| Antenna Timeout (ms)* | Sets the maximum time period (ms) during which each antenna is used for a READ or WRITE command. Range is 0 to 65534. | 50 |
| ID Tries* | Sets the number of times an attempt is made to find tags before a response is returned to a READ or WRITE command. Range is 1 to 254. | 1 |
| Antenna Tries* | Sets the maximum time period (ms) during which each antenna is used for a READ or WRITE command. Range is 1 to 254. | 3 |
| Schedule Option* | Controls the behavior of ANTTIMEOUT, ANTTRIES, IDTIMEOUT, and IDTRIES. | 1 |
| Read Tries* | Sets the number of times an attempt is made to read data from a tag before a response is returned to a READ command. Range is 0 to 254. | 3 |
| Write Tries* | Sets the number of times an attempt is made to write data to a tag before a response is returned to a WRITE command. Range is 1 to 254. | 3 |
| Initialization Tries* | Sets the initialization tries variable in the reader. Range is 1 to 254. | 1 |
| Lock Tries* | Sets the number of times an attempt is made to lock data on a tag before a response is returned to a Lock command. Range is 1 to 254. | 3 |

*IP30 RFID Reader Settings only.

| Setting | Description | Default |
|-----------------|--|---------|
| Select Tries* | Sets the number of times a group select is attempted. A group select is the command used to start the identify process. Range is 1 to 254. | 1 |
| Unselect Tries* | Sets the number of times a group unselect is attempted. Range is 1 to 254. | 1 |

*IP30 RFID Reader Settings only.

Filter Settings

Use the Filter Settings to modify or reject data strings.

Filter Settings

| Setting | Description | Default |
|--------------------|--|---------|
| Read filter script | Filter applied to raw tag results. | None |
| Debug level | Degree of detail in debug messages. The default level is 0, no information. Higher levels emit more information. Level 4 emits the most information. | 0 |

Notification Settings

Use the Notification Settings to configure how your computer responds when you scan a barcode.

Notification Settings

| Setting | Description | Default |
|-------------------------|---|----------|
| Good Read Notification | Enables or disables a good read notification. The notification consists of a green blink of the Good Read LED, a short beep, and an optional short vibration. | Enabled |
| Bad Read Notification | Enables or disables notification of a failed scan. The notification consists of a red blink of the Good Read LED, an error beep, and an optional short vibration. | Disabled |
| Vibrate On Notification | Enables or disables whether the computer vibrates when there is a good or bad read. | Disabled |

Trigger Settings

Use the Trigger Settings to configure how the scan trigger functions. Trigger Settings is only available for some RFID reader models.

Trigger Settings

| Setting | Description | Default |
|-----------------------|--|---------|
| Enable reader trigger | Enable activating a scan by pressing the trigger on the RFID reader. | Enabled |

Data Processor Settings

Use the Data Processor Settings to specify how RFID tag data is processed by the computer.



Data Processor Settings

| Setting | Description | Default |
|----------------------------|---|------------|
| Wedge | Enable or Disable the wedge feature. Wedge must be enabled to pair the mobile device with an RFID reader using the RFID Pairing app. | Enabled |
| Wedge Method | Specify wedge method: Standard or Keyboard. In Standard mode, the wedged data displays in a block format. In Keyboard mode, the wedged data is displayed character by character, similar to typing on a keyboard. | Standard |
| Charset | Select the character set to use when interpreting the tag binary data into a string. | ISO-8859-1 |
| Prefix | Defines the string added to the front of the tag data. | None |
| Suffix | Defines the string added after the tag data. | None |
| Wedge as Keys | List of character values to wedge as keys, represented as a comma-separated list of decimal values. | 9,10,13 |
| Launch Browser | Enable or disable a browser being launched when the tag data starts with http:// or https://. The browser opens using the tag data as a URL. | Enabled |
| Tag to Intent | Launches an app specified by the tag when data begins with //. | Enabled |
| Launch EZConfig | Enable or disable special handling of EZConfig barcodes. Applies to EZConfig barcodes that are encoded with the Aztec symbology and contain specific header data. Corresponds to BarcodeReader property: PROPERTY_DATA_PROCESSOR_LAUNCH_EZ_CONFIG | Enabled |
| Data intent | | |
| Data intent | Data intent. | Disabled |
| Action | Data intent action property. | None |
| Category | Data intent category property. | None |
| Package name | Data intent package name. | None |
| Class name | Data intent class name. | None |
| Extra key | Data intent extra key name. | None |
| Data Editing Plugin | | |
| Data Editing Plugin | Name of the plugin used to manipulate tag data. | None |
| Edit settings | The edit data settings property. | None |

Add an RFID Profile

The mobile computer has a default profile for each RFID Reader model. You can also create custom profiles as needed for your use case. Profiles are created for the RFID model.

To create an RFID profile for a custom app on the computer:


1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **RFID** > <RFID Reader model>.
3. Tap  in the upper right corner of the app screen.
4. Take one of the following actions:
 - Tap the **profile name** field and then add a new name.

OR

- Tap the **select an application** option, and then choose an app from the list.

The new profile appears on the RFID profile list for the selected device type. You can now select and modify the scan settings for the new profile.

Delete an RFID Profile

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **RFID** > <Device type>.
3. Tap and hold the profile you want to delete, select **Delete** and then click **OK**.

MANAGE AND MAINTAIN THE COMPUTER

Use this chapter to understand how to upgrade software and to reset and maintain the computer.

About Software Updates and Cyber Security

Cyber security best practices include keeping your device apps and OS up to date. To help, Honeywell offers maintenance patches, security updates and operating system upgrades through our Honeywell Edge services.

Availability and cost depend on the following:

- Date of purchase of the device or software app.
- Warranty status.
- Service agreement status (devices) or Maintenance plan status (apps).

To learn more about Honeywell Edge Services, go to <https://sps.honeywell.com/us/en/services/productivity/support-services>.



Honeywell recommends routinely checking honeywell.com/SPS-cyber-security for critical Cyber Security Notifications and to download the latest Network and Security Guides.

Software Downloads

Product support is available online through [Technical Support](#). Software updates can be accessed through the [Software Downloads](#) portal. You will need to create a login account for portal access. Additional information such as purchased date, service agreement number, maintenance plan number, or software license number may be required for downloads.

1. Go to honeywell.com/PSSsoftware-downloads.
2. Create a login account if you have not already created one.
3. Install the Honeywell Download Manager tool. See “Note” on the portal page. This tool is required for downloads.
4. Locate the app or upgrade you want to download in the Software directory.



5. If prompted, enter additional information, and click **Submit**.
6. Select **Download**. Follow the prompts to download the file.

About Transferring Files via USB Connection

If you plan on using a USB connection to transfer files to the mobile computer, make sure you set the USB connection to allow file transfers. To learn more, see [Configure USB Connection and Transfer Files](#) on page 24.

Install Software Apps with AutoInstall

Important: *The mobile computer must have power for the entire length of the install process or it could become unstable. Do not attempt to remove the battery during the process.*

1. Swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Provisioning Mode**.
3. Tap the toggle button to turn Provisioning Mode **On**.
4. Save the Android application file (*.zip or *.apk) in one of the following folders on the mobile computer:
 - **Internal shared storage\honeywell\autoinstall**
Files saved to this folder for installation do not persist when a Full factory reset or Enterprise data reset is performed.
 - **IPSM card\honeywell\autoinstall**
Files saved to this folder for installation do not persist when a Full factory reset is performed. However, the software does persist if an Enterprise data reset is performed.
5. Swipe up from the bottom of the Home screen to access all apps.
6. Tap **AutoInstall**  and verify **Enable AutoInstall** is selected.
7. Tap **Packages Upgrade** from the AutoInstall Settings screen.



If required by the app, the computer may automatically initiate a reboot before starting the installation process. When the installation is finished, a message appears or the unit finishes rebooting and the lock screen appears.
8. Once installation is complete, turn Provisioning Mode **Off**.

Note: *Some updates do not require the computer to reboot before installation.*

Optional microSD Card Method

The mobile computer comes equipped with a microSD card socket. You can install an upgrade from a microSD card that you insert in the computer.

Important: *The computer must have power for the entire length of the install process or it could become unstable. Do not attempt to remove the battery during the process.*

1. On the computer, swipe up from the bottom of the Home screen to access all apps.
2. Tap **Settings**  > **Honeywell Settings** > **Provisioning Mode**.
3. Tap the toggle button to turn Provisioning Mode **On**.
4. Swipe up from the bottom of the Home screen to access all apps.
5. Tap **AutoInstall**  and verify **Enable AutoInstall** is selected .
6. Press and hold the **Power** button, and then tap **Power off**.
7. On your workstation (e.g., laptop, desktop computer), format the microSD card and create a **\honeywell\autoinstall** folder on the root of the card.
8. Save the upgrade file in the **autoinstall** folder.
9. Install the microSD card in the computer and then press the **Power** button.

The computer automatically runs the upgrade found in the autoinstall folder on the card. The system update screen appears during the upgrade process. When the upgrade is finished, the lock screen appears.

10. Once installation is complete, turn Provisioning Mode **Off**.

About the Honeywell Upgrader

Use the Honeywell Upgrader app (HUpgrader) to automatically search for and install Over-the-Air (OTA) operating system updates from a remote server. The app can also be used to manually initiate a search for OS updates, update the OS using a file downloaded to the mobile device, and downgrade the operating system to a previous version. Refer to the HUpgrader User Guide available at sps.honeywell.com for more information.

Restart (Reboot) the Computer

You may need to reboot the computer to correct conditions where an application stops responding to the system.

1. Save your files and close any open applications.
2. Press and hold the **Power** button until the options screen appears.

3. Tap **Restart**. The computer restarts.

If the touch panel display is unresponsive:

- Press and hold the **Power** button for approximately 8 seconds until the computer reboots.

About an Enterprise Data Reset

You can perform an Enterprise data reset if a Reboot did not improve the condition and all other troubleshooting methods have not resolved the issue. This method provides a clean configuration for troubleshooting by erasing all data from the Internal shared storage location on the computer. Data is not erased from the IPSM Card location.




Caution: An Enterprise data reset results in data loss. Only perform this procedure if all other recovery methods have failed. All personal content is erased, including, but not limited to emails, pictures, contacts, Google account information, system settings, and app settings.

Note: *This method of recovery may not be available if your system administrator has set policies to prevent the reset use.*

Before You Begin

- If you recently reset your Google Account password, wait 24 hours before performing a Enterprise data reset.
- Make sure you have your screen lock password, PIN or pattern if you activated one. You will need this to reset the computer.
- If you have a Google Account, back up your data and settings to your Google Account so you can restore them if needed.
- Connect the computer to an external power source or make sure you have a full battery charge.
- Make sure you have an Internet connection.

Enterprise Data Reset the Computer

1. Swipe up from the bottom of the Home screen to access all apps.
2. Select **Settings**  > **System** > **Reset options**.
3. Tap **Enterprise data reset**.
4. Tap **Erase all data**.
5. If prompted, type your screen lock security pattern, PIN, or password.

6. Tap **Erase all data**. A message appears informing you an Enterprise data reset is being performed.

About a Full Factory Reset

A full factory reset should only be performed if you have exhausted all other troubleshooting options. This method reverts the computer back to the factory state by erasing all data in Internal shared storage and the IPSM Card storage locations on the computer.




Caution: A Full factory reset results in data loss. Perform this procedure only if all other recovery methods have failed and have no other option. All personal content is erased, including, but not limited to emails, pictures, contacts, Google account information, system settings and app settings.

Note: *This method of recovery may not be available if your system administrator has set policies to prevent the reset use.*

Before You Begin

- If you added a Google Account to the computer, make sure you have your Google username and password associated with the computer. If you do not have the username and password, you will not be able to use the computer after the reset. This is a security measure that prevents unauthorized users from using the device if they try a Full factory reset.
- If you did not add a Google Account to the computer, the extra security level is not enabled and you will not need a Google username and password.
- If you recently reset your Google Account password, wait 24 hours before performing a Full factory reset.
- Connect the computer to an external power source or make sure you have a full battery charge.
- Make sure you have an Internet connection.

Full Factory Reset the Computer

1. Swipe up from the bottom of the Home screen to access all apps.
2. Select **Settings**  > **System** > **Reset options**.
3. Tap **Erase all data (factory reset)**.
4. Tap **Erase all data**.
5. If prompted, type your screen lock security pattern, PIN, or password.
6. Tap **Erase data**. A message appears informing you a Factory data reset is being performed.

Repairs

Repairs and/or upgrades are not to be performed on this product. These services are to be performed only by an authorized service center (see [Customer Support](#) on page ix).

Maintenance

Your device provides reliable and efficient operation with a minimum of care. Although specific maintenance is not required, the following sections describe periodic checks to ensure dependable operation.

Clean the Computer

A cleaning guide is provided on the product page at sps.honeywell.com. Please refer to this guide for a list of approved cleaners for your device.

Note: *Reading performance may degrade if the scanner window is not clean. If the window is visibly dirty, or if the scanner is not operating well, clean the window.*



Caution: Do not submerge the computer in water or a cleaning solution. Do not use abrasive wipes or cloths on the windows and touch screen. Abrasive wipes may scratch the windows and touch screen. Never use solvents (e.g., acetone) on the housing or window. Solvents may damage the computer finish, the windows, or touch screen.

Caution: Ensure all components are dry prior to mating the computer with charging accessories or other peripheral devices. Mating wet components may cause damage not covered by the warranty.

About Disinfectant-ready Models

Some configurations of the CT40/CT40 XP computer are available with external plastic housings that are designed to resist the effects of harsh chemicals. These specialty mobile computer configurations are equipped with disinfectant-ready housings (DRH) for the healthcare and/or general-purpose markets.

For general-purpose models, please refer to the General Purpose Disinfectant-Ready Housing Cleaning Guide located on your device's product page at sps.honeywell.com.

For healthcare models, please refer to the Healthcare Disinfectant-Ready Housing Cleaning Guide located on your device's product page at sps.honeywell.com.

SPECIFICATIONS

Computer Agency Information


CT40 and CT40 XP mobile computers meet or exceed the requirements of all applicable standards organizations for safe operation. The best way to ensure safe operation is to use the mobile computer according to the agency guidelines on the product regulatory sheet, quick start guide, battery insert, and in this user guide. Read all guidelines before using your computer.

Product documentation and public certificates are available for download from sps.honeywell.com.

Label Locations

Labels inside the battery compartment contain information about the computer, including compliance information, model number, serial number, IMEI number (CT40-L1N/CT40P-L1N models only), and MAC address. Laser safety labeling is located on the back of the computer.

Model Dependent Identification Numbers
(e.g. Serial Number, IMEI, MEID, MAC address)



Physical and Environmental Specifications

1. Go to sps.honeywell.com.
2. Type CT40 or CT40 XP in the Search box, and then press **Enter**.
3. Click on the product link in the search results.
4. Select one of the following tabs:
 - **Specifications**
View System Architecture, Wireless Connectivity, Mechanical, and Environmental specifications.
 - **Resources**
Download the Data Sheet, Accessory Guide, Quick Start Guide, User Guide, Regulatory Information, Battery Information, and other product documentation.

Imager Specifications

The CT40 series high-performance imager options:

- N3601 Imager
- N6603 Slim Imager
- N6703 Ultra-Slim Imager
- N6803-FR FlexRange™ Imager
- S0703-SR Standard Range Imager

The CT40 XP series high-performance imager options:

- N6700 Imager
- N6703 Ultra-Slim Imager
- N6803-FR FlexRange Imager
- S0703-SR Standard Range Imager

Barcode Symbologies

The computer supports the following barcode symbologies:

| 1D Symbologies | | 2D Symbologies | | Postal Codes | |
|----------------|----------|----------------|----------|--------------|----------|
| | Default | | Default | | Default |
| Codabar | Enabled | Aztec Code | Enabled | China Post | Disabled |
| Code 39 | Enabled | Codablock A | Disabled | Korean Post | Disabled |
| Code 11 | Disabled | Codablock F | Disabled | 2D Postal | Disabled |
| Code 93 | Disabled | DataMatrix | Enabled | | |

| 1D Symbologies | | 2D Symbologies | | Postal Codes | |
|--------------------|----------|----------------|----------|--------------|---------|
| | Default | | Default | | Default |
| Code 128 | Enabled | DotCode | Disabled | | |
| Composite | Disabled | Grid Matrix | Disabled | | |
| EAN-8 | Enabled | HanXin | Disabled | | |
| EAN-13 | Enabled | Maxicode | Disabled | | |
| GS1-128 | Enabled | Micro PDF 417 | Disabled | | |
| GS1 DataBar | Disabled | PDF 417 | Enabled | | |
| IATA 2 of 5 | Disabled | QR Code | Enabled | | |
| Standard 2 of 5 | Disabled | OCR | Disabled | | |
| Interleaved 2 of 5 | Enabled | Digimarc | Disabled | | |
| Matrix 2 of 5 | Disabled | TLC 39 | Disabled | | |
| MSI | Disabled | | | | |
| Telepen | Disabled | | | | |
| Trioptic | Disabled | | | | |
| UPC/EAN | Enabled | | | | |
| UPC-A | Enabled | | | | |
| UPC-E | Enabled | | | | |

Note: To learn about changing the symbology settings, see [Change the Scanner Settings](#) on page 40.

N3601 Imager Reading Distances

Note: Time to Read and Depth of Field are impacted if the barcode symbol is at the edge of the image.

Guaranteed Specs

| Focus | | Standard Range | |
|------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 100% UPC-A | mm | 61 | 470 |
| | in. | 2.4 | 18.5 |
| 5 mils Code 39 | mm | 79 | 175.3 |
| | in. | 3.1 | 6.9 |
| 10 mils Code 39 | mm | 31 | 455 |
| | in. | 1.2 | 17.9 |
| 20 mils Code 39 | mm | 66.04 | 655.3 |
| | in. | 2.6 | 25.8 |
| 15mils Code 128 | mm | 61 | 599.4 |
| | in. | 2.4 | 23.6 |
| 6.7 mils PDF 417 | mm | 64 | 203.2 |
| | in. | 2.5 | 8.0 |
| 15 mils QR | mm | 61 | 270 |
| | in. | 2.4 | 10.6 |

Typical Specs

| Focus | | Standard Range | |
|-----------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 100% UPC-A | mm | 61 | 521 |
| | in. | 2.4 | 20.5 |
| 5 mil Code 39 | mm | 76.2 | 188 |
| | in. | 3.0 | 7.4 |
| 10 mil Code 39 | mm | 31 | 455 |
| | in. | 1.2 | 17.9 |
| 20 mil Code 39 | mm | 66.04 | 655.3 |
| | in. | 2.6 | 25.8 |
| 15mil Code 128 | mm | 61 | 599.4 |
| | in. | 2.4 | 23.6 |
| 6.7 mil PDF 417 | mm | 64 | 203.2 |
| | in. | 2.5 | 8.0 |
| 15 mil QR | mm | 51 | 305 |
| | in. | 2.0 | 12 |

N3601 Imager Field of View/Resolution

| Focus | Standard Range (SR) |
|----------------------------------|---------------------|
| Horizontal Field Angle (degrees) | ±24.5 ±1.5° |
| Vertical Field Angle (degrees) | ±18.5 ±1.5° |

Note: DPI can be calculated based on the following formula:
 Horizontal DPI = 832 pixels/width of horizontal field of view (inches)
 Vertical DPI = 640 pixels/width of vertical field of view (inches)

N6603 Slim Imager Reading Distances

Note: Time to Read and Depth of Field are impacted if the barcode symbol is at the edge of the image.

Guaranteed Specs

| Focus | | Standard Range | |
|------------------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39/128 | mm | 91.4 | 142.2 |
| | in. | 3.6 | 5.6 |
| 10 mils Code 39/128 | mm | 48.3 | 305 |
| | in. | 1.9 | 12.0 |
| 100% UPC | mm | 53.3 | 384 |
| | in. | 2.1 | 15.1 |
| 6.7 mils PDF 417 | mm | 64 | 168 |
| | in. | 2.5 | 6.6 |
| 10 mils DataMatrix/ Aztec | mm | 74 | 185.4 |
| | in. | 2.9 | 7.3 |

Typical Specs

| Focus | | Standard Range | |
|------------------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39/128 | mm | 64 | 163 |
| | in. | 2.5 | 6.4 |
| 10 mils Code 39/128 | mm | 28 | 330.2 |
| | in. | 1.1 | 13.0 |
| 100% UPC | mm | 46 | 419.1 |
| | in. | 1.8 | 16.5 |
| 6.7 mils PDF 417 | mm | 46 | 185.4 |
| | in. | 1.8 | 7.3 |
| 10 mils DataMatrix/ Aztec | mm | 53.3 | 203.2 |
| | in. | 2.1 | 8.0 |

N6603 Slim Imager Field of View/Resolution

| Focus | Standard Range (SR) |
|----------------------------------|---------------------|
| Horizontal Field Angle (degrees) | ±21.2 ±3.5° |
| Vertical Field Angle (degrees) | ±16.5 ±3.5° |

Note: *DPI can be calculated based on the following formula:
Horizontal DPI = 832 pixels/width of horizontal field of view (inches)
Vertical DPI = 640 pixels/width of vertical field of view (inches)*

N6700 Imager/N6703 Ultra-Slim Imager

Note: *Time to Read and Depth of Field are impacted if the barcode symbol is at the edge of the image.*

Guaranteed Specs

| Focus | | Standard Range | |
|-----------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 3 mils Code 39 | mm | 129.03 | 164.1 |
| | in. | 5.08 | 6.46 |
| 5 mils Code 39 | mm | 79 | 270 |
| | in. | 3.11 | 10.63 |
| 10 mils Code 39 | mm | 34.04 | 450.1 |
| | in. | 1.34 | 17.72 |

| Focus | | Standard Range | |
|---------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 20 mils Code 39 | mm | 38.1 | 674 |
| | in. | 1.50 | 26.53 |
| 13 mils 100% UPC-A | mm | 38.1 | 515 |
| | in. | 1.50 | 20.27 |
| 13 mils 20% UPC-A | mm | 83.1 | 205 |
| | in. | 3.27 | 8.07 |
| 15 mils Code 128 | mm | 36.1 | 572.01 |
| | in. | 1.42 | 22.52 |
| 10 mils Data Matrix | mm | 83.1 | 236 |
| | in. | 3.27 | 9.29 |
| 5 mils PDF 417 | mm | 119 | 177.04 |
| | in. | 4.68 | 6.97 |
| 6.7 mils PDF 417 | mm | 96.01 | 236 |
| | in. | 3.78 | 9.29 |
| 6.7 mils QR | mm | 123 | 147.1 |
| | in. | 4.84 | 5.79 |
| 15 mils QR | mm | 33.02 | 390 |
| | in. | 1.30 | 15.35 |

Typical Specs

| Focus | | Standard Range | |
|---------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 3 mils Code 39 | mm | 106 | 176.02 |
| | in. | 4.17 | 6.93 |
| 5 mils Code 39 | mm | 70 | 301 |
| | in. | 2.75 | 11.85 |
| 10 mils Code 39 | mm | 29 | 517 |
| | in. | 1.14 | 20.35 |
| 20 mils Code 39 | mm | 35.1 | 800.1 |
| | in. | 1.38 | 31.5 |
| 13 mils 100% UPC-A | mm | 34.04 | 573.02 |
| | in. | 1.34 | 22.56 |
| 13 mils 20% UPC-A | mm | 79 | 228.1 |
| | in. | 3.11 | 8.98 |
| 15 mils Code 128 | mm | 34.04 | 650 |
| | in. | 1.34 | 25.59 |
| 10 mils Data Matrix | mm | 72 | 297 |
| | in. | 2.83 | 11.69 |

| Focus | | Standard Range | |
|------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils PDF 417 | mm | 105 | 181 |
| | in. | 4.13 | 7.12 |
| 6.7 mils PDF 417 | mm | 84.1 | 244.1 |
| | in. | 3.31 | 9.61 |
| 6.7 mils QR | mm | 105 | 169 |
| | in. | 4.13 | 6.65 |
| 15 mils QR | mm | 27 | 414.02 |
| | in. | 1.06 | 16.30 |

N6700 Imager/N6703 Imager Field of View/Resolution

| Focus | Standard Range (SR) |
|----------------------------------|---------------------|
| Horizontal Field Angle (degrees) | 48 ± 2° |
| Vertical Field Angle (degrees) | 31 ± 2° |

DPI can be calculated based on the following formula:

Horizontal DPI = 1280 pixels/width of horizontal field of view (inches)

Vertical DPI = 800 pixels/width of vertical field of view (inches)

N6803-FR FlexRange Imager

The depth of field measurements used the following parameters:

- Distances are measured from the front of the Imager.
- +23 °C (+73 °F), 200 lux for guaranteed, 200 lux for typical.
- Photographic quality codes

Note: *Time to Read and Depth of Field will be impacted if the barcode symbol is at the edge of the image.*

Guaranteed Specs

| Focus | | Standard Range | |
|---|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39 | mm | 138 | 365 |
| | in. | 5.43 | 14.4 |
| ¹ Minimum distance depends on the length of the barcode. ² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mils code height of 3 inches. | | | |

| Focus | | Standard Range | |
|---|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 10 mils Data Matrix | mm | 152 | 387 |
| | in. | 6 | 15.23 |
| 10 mils Code 39 | mm | 94 | 1198 |
| | in. | 4 | 47.2 |
| 13 mils UPC-A | mm | 68 | 1437 |
| | in. | 3 | 57 |
| 15 mils Code 128 | mm | 66 | 1571 |
| | in. | 3 | 62 |
| 20 mils Code 39 | mm | 63 | 2161 |
| | in. | 3 | 85.1 |
| 100 mils Data Matrix ¹ | mm | - | 4505 |
| | in. | - | 177.4 |
| 55 mils Code 39 ¹ | mm | - | 6546 |
| | in. | - | 258 |
| 100 mils Code 39 ^{1,2} | mm | - | 9843 |
| | in. | - | 388 |
| ¹ Minimum distance depends on the length of the barcode. ² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mils code height of 3 inches. | | | |

Typical Specs

| Focus | | Standard Range | |
|--|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39 | mm | 122 | 414 |
| | in. | 5 | 16.3 |
| 10 mils Data Matrix | mm | 135 | 419 |
| | in. | 5.3 | 17 |
| 10 mils Code 39 | mm | 85 | 1368 |
| | in. | 3.4 | 54 |
| 13 mils UPC-A | mm | 60 | 1600 |
| | in. | 2.4 | 63 |
| 15 mils Code 128 | mm | 58 | 1894 |
| | in. | 2.3 | 75 |
| 20 mils Code 39 | mm | 56 | 2645 |
| | in. | 2.2 | 104.1 |
| ¹ Minimum distance depends on the length of the barcode. ² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mil code height of 3 inches. | | | |

| Focus | | Standard Range | |
|-----------------------------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 100 mils Data Matrix ¹ | mm | - | 5641 |
| | in. | - | 222.1 |
| 55 mils Code 39 ¹ | mm | - | 7159 |
| | in. | - | 282 |
| 100 mils Code 39 ^{1,2} | mm | - | 10815 |
| | in. | - | 426 |

¹ Minimum distance depends on the length of the barcode.
² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mil code height of 3 inches.

N6803-FR FlexRange Imager Field of View/Resolution

Near Field Optical System

- Horizontal FOV: 48°
- Vertical FOV: 21°

Note: *DPI can be calculated based on the following formula:
Horizontal DPI = 1920 pixels/width of horizontal field of view (inches)
Vertical DPI = 800 pixels/width of vertical field of view (inches)*

Far Field Optical System

- Horizontal FOV: 20°
- Vertical FOV: 12°

*DPI can be calculated based on the following formula:
Horizontal DPI = 1280 pixels/width of horizontal field of view (inches)
Vertical DPI = 800 pixels/width of vertical field of view (inches).*

S0703-SR Standard Range Imager

The depth of field measurements used the following parameters:

- Distances are measured from the front of the Imager.
- +23 °C (+73 °F), 0 lux for guaranteed, 200 lux for typical.
- Photographic quality codes

Note: *Time to Read and Depth of Field will be impacted if the barcode symbol is at the edge of the image.*

Guaranteed Specs

| Focus | | Standard Range | |
|---|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39 | mm | 79 | 270 |
| | in. | 3.11 | 10.63 |
| 10 mils Code 39 | mm | 40 | 425 |
| | in. | 1.57 | 16.73 |
| 20 mils Code 39 | mm | 44 | 674 |
| | in. | 1.73 | 26.53 |
| 13 mils UPC-A | mm | 44 | 493 |
| | in. | 1.73 | 19.41 |
| 15 mils Code 128 | mm | 42 | 572 |
| | in. | 1.65 | 22.52 |
| 10 mils Data Matrix | mm | 83 | 236 |
| | in. | 3.27 | 9.29 |
| 6.7 mils PDF417 | mm | 96 | 236 |
| | in. | 3.78 | 9.29 |
| 15 mils QR | mm | 39 | 390 |
| | in. | 1.54 | 15.35 |
| ¹ Minimum distance depends on the length of the barcode. ² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mils code height of 3 inches. | | | |

Typical Specs

| Focus | | Standard Range | |
|---|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 5 mils Code 39 | mm | 70 | 301 |
| | in. | 2.75 | 11.85 |
| 10 mils Code 39 | mm | 40 | 517 |
| | in. | 1.57 | 20.35 |
| 20 mils Code 39 | mm | 44 | 800 |
| | in. | 1.73 | 31.50 |
| 13 mils UPC-A | mm | 44 | 573 |
| | in. | 1.73 | 22.56 |
| 15 mils Code 128 | mm | 42 | 650 |
| | in. | 1.65 | 25.59 |
| 10 mils Data Matrix | mm | 72 | 297 |
| | in. | 2.83 | 11.69 |
| ¹ Minimum distance depends on the length of the barcode. ² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mils code height of 3 inches. | | | |

| Focus | | Standard Range | |
|-----------------|-----|----------------|--------------|
| Symbology | | Near Distance | Far Distance |
| 6.7 mils PDF417 | mm | 84 | 244 |
| | in. | 3.31 | 9.61 |
| 15 mils QR | mm | 39 | 414 |
| | in. | 1.54 | 16.30 |

¹ Minimum distance depends on the length of the barcode.
² Typical code wide to narrow elemental ratio is 3:1. Minimum 100 mils code height of 3 inches.

S0703-SR Standard Range Imager Field of View/Resolution

| Focus | Standard Range (SR)/ High Density (HD) |
|----------------------------------|---|
| Horizontal Field Angle (degrees) | 44 ± 2° |
| Vertical Field Angle (degrees) | 28 ± 2° |

Note: *DPI can be calculated based on the following formula:
Horizontal DPI = 1280 pixels/width of horizontal field of view (inches)
Vertical DPI = 800 pixels/width of vertical field of view (inches)*

Honeywell
855 S. Mint Street
Charlotte, NC 28202

sps.honeywell.com